



MD600 Series Compact AC Drive Hardware Guide



Industrial
Automation



Intelligent
Elevator



New Energy
Vehicle



Industrial
Robot



Rail
Transit



Data code 19012234B02

Preface


Introduction

The MD600 is a compact, general-purpose, and cost-effective AC drive for small automation equipment. Supporting Modbus RTU and CAN communication protocols, it features a compact size and high-performance open-loop vector control and can drive synchronous and asynchronous motors. The MD600 is widely used in small automation equipment in fields such as crystalline silicon, lithium battery, carpentry, logistics, cables, packaging, and machine tools.

This guide describes product selection, mechanical design, electrical design, common EMC problems and solutions, and product certifications and standards.

More Data

The following figure and table describe document codes and document introduction of the drive.



| No. | Name | Date Code | Description |
|-----|---|-----------|--|
| ① | MD600 Series Compact AC Drive | 19120393 | This guide describes the product positioning, highlights, application scenarios, and selection specifications of the drive. |
| ② | MD600 Series Compact AC Drive Quick Start Guide | 19012337 | This guide describes the installation and operation, common faults and troubleshooting, and parameter settings of the drive. |
| ③ | MD600 Series Compact AC Drive Hardware Guide (this guide) | 19012234 | This guide describes product selection, mechanical design, electrical design, common EMC problems and solutions, and product certifications and standards. |

| No. | Name | Date Code | Description |
|-----|---|------------|--|
| ④ | MD600 Series Compact AC Drive Function Guide | 19012238 | This guide describes the basic function configuration, function application, communication configuration, troubleshooting, and parameters of the drive. |
| ⑤ | MD600 Series Compact AC Drive Parameter Guide | 19012528 | This guide describes parameters and fault codes. |
| ⑥ | MD600 Series Compact AC Drive User Guide | PS00012434 | This guide describes product selection, mechanical design, electrical design, quick installation and operation, function application, communication configuration, troubleshooting, common EMC problems and solutions, and product certifications and standards. |

Revision History

| Date | Version | Description |
|----------------|---------|---|
| September 2024 | B02 | <p>Updated</p> <ul style="list-style-type: none"> • Updated "1.4 Product Model List" on page 18. • Updated "3.5.1 Introduction to Control Circuit Terminals" on page 46. • Updated "3.5.2 Wiring Descriptions of Control Circuit Terminals" on page 50. • Updated "9.4 Technical Specifications" on page 82. • Updated "9.5.3.1 Main Circuit Cables" on page 89. • Updated "9.5.3.2 Control Circuit Cable" on page 92. • Updated "9.5.4.1 Circuit Breaker, Fuse, and Electromagnetic Contactor" on page 93. • Updated "9.5.4.6 Braking Resistor" on page 105. <p>Made minor corrections.</p> <p>Added the following:</p> <ul style="list-style-type: none"> • Shipment Check • Power Supply Compatibility Check • Unpacking, Storage, and Transportation • AC Drive Installation • AC Drive Wiring |
| March 2024 | B01 | <p>Added specifications related to 5.5 kW models.</p> <p>Added the MD-BP-M operating panel.</p> <p>Optimized descriptions of the vibration and shock resistance function in section Installation Environment.</p> <p>Made minor corrections.</p> <p>Note: To support the MD-BP-M operating panel, the MD600 software version must be A2-22 = 60.02/A2-23 = 61.02/A2-24 = 0.28/A2-25 = 0.31 or later. If the current MD600 software version does not support the MD-BP-M, contact the service personnel of the manufacturer to upgrade the software.</p> |

| Date | Version | Description |
|---------------|---------|---|
| December 2023 | B00 | <ul style="list-style-type: none"> • Optimized the document structure. • Modified the section Installation Environment and compiled the system connection diagram and system composition table into one section. • Modified the section Installation Tool Preparations and deleted the installation of the guide rail in section Screws. • Added EMC-Compliant Control Cabinet Design. • Added the internal circuit diagram in Electrical Connection Diagram. • Modified the section Cable Preparations and compiled the cable overview and cable handling into one section. • Modified Peripheral Electrical Component Design to Basic Electrical Safety Precautions and optimized the content. • Modified Communication Cable Selection and updated the termination resistor in the CAN and RS485 communication topology diagram. • Added Application Instance. • Updated electrical specifications, technical specifications, and option specifications in Specifications. • Changed the IP rating from IP20 to IP40 (except for the power distribution wiring and capacitor ventilation) in Electrical Specifications. • Added relay specifications in Technical Specifications. • Made minor corrections. |
| June 2023 | A00 | Initial release |

Access to the Guide

This guide is not delivered with the product. You can obtain the PDF version by the following methods:

- Do keyword search under Service and Support at <http://www.inovance.com>.
- Scan the QR code on the product with your smart phone.
- Scan the QR code below to install the app, where you can search for and download manuals.



Warranty Disclaimer

Inovance provides warranty service within the warranty period (as specified in your order) for any fault or damage that is not caused by improper operation of the user. Maintenance will be charged after the warranty expires.

Within the warranty period, maintenance fee will be charged for the following damage:

- Damage caused by operations not following the instructions in the user guide
- Damage caused by fire, flood, or abnormal voltage
- Damage caused by unintended use of the product
- Damage caused by use beyond the specified scope of application of the product
- Damage or secondary damage caused by force majeure (natural disaster, earthquake, and lightning strike)

The maintenance is charged according to the latest Price List of Inovance. If otherwise agreed upon, the terms and conditions in the agreement shall prevail.

Table of Contents

| | |
|---|----|
| Preface | 1 |
| Fundamental Safety Instructions | 9 |
| 1 Hardware Description | 15 |
| 1.1 Product Overview | 15 |
| 1.2 Model and Nameplate | 16 |
| 1.3 Components | 17 |
| 1.4 Product Model List | 18 |
| 1.5 System Connection | 19 |
| 2 Mechanical Design | 22 |
| 2.1 Installation Environment | 22 |
| 2.2 Installation Direction | 23 |
| 2.3 Installation Tool Preparations | 23 |
| 2.4 Cabinet Design | 25 |
| 2.4.1 Cabinet Layout | 25 |
| 2.4.2 Product Dimensions | 29 |
| 2.5 EMC Design | 30 |
| 2.5.1 Electromagnetic Compatibility | 30 |
| 2.5.2 EMC-Compliant Control Cabinet Design | 30 |
| 2.6 Heat Dissipation Design | 31 |
| 2.6.1 Ventilation Requirements | 31 |
| 2.6.1.1 Air Duct Design | 32 |
| 2.6.1.2 Air Outlet and Inlet | 32 |
| 2.6.2 Fan Design | 36 |
| 3 Electrical Design | 39 |
| 3.1 Electrical Wiring Diagram | 39 |
| 3.2 Cable Preparations | 40 |
| 3.3 Basic Electrical Safety Precautions | 42 |
| 3.3.1 Selecting Power Supply Isolation Devices | 42 |
| 3.3.2 Selecting Main Contactors | 42 |
| 3.3.3 Short Circuit Protection | 42 |
| 3.3.4 Selecting Motors | 43 |
| 3.3.5 Checking the Compatibility of the Motor and Drive | 43 |
| 3.3.6 Selecting Surge Protection Devices | 43 |
| 3.3.7 Requirements on Power Grid System Compatibility | 43 |
| 3.4 Main Circuit Wiring | 44 |
| 3.4.1 Introduction to Main Circuit Terminals | 44 |
| 3.4.2 Wiring Description of Main Circuit Terminals | 45 |

| | |
|--|-----|
| 3.5 Control Circuit Wiring | 46 |
| 3.5.1 Introduction to Control Circuit Terminals | 46 |
| 3.5.2 Wiring Descriptions of Control Circuit Terminals | 50 |
| 3.6 Selection of Communication Cables | 56 |
| 3.6.1 RS485 Communication Cable | 56 |
| 3.6.2 CAN Communication Cable | 56 |
| 4 Shipment Check | 64 |
| 5 Power Supply Compatibility Check | 65 |
| 6 Unpacking, Storage, and Transportation | 66 |
| 7 AC Drive Installation | 68 |
| 7.1 Pre-installation Check | 68 |
| 7.2 Backplate Mounting | 68 |
| 7.3 Guide Rail Installation | 69 |
| 7.4 Post-installation Check | 70 |
| 8 AC Drive Wiring | 71 |
| 8.1 Pre-wiring Check | 71 |
| 8.2 Main Circuit Wiring | 71 |
| 8.3 Post-wiring Check | 73 |
| 9 Specifications | 75 |
| 9.1 List of Model Selection | 75 |
| 9.2 Selection Instance | 78 |
| 9.3 Electrical Specifications | 79 |
| 9.4 Technical Specifications | 82 |
| 9.5 Option Specifications | 84 |
| 9.5.1 List of Options | 84 |
| 9.5.2 Operating Panel | 86 |
| 9.5.3 Cable | 89 |
| 9.5.3.1 Main Circuit Cables | 89 |
| 9.5.3.2 Control Circuit Cable | 92 |
| 9.5.3.3 Cable Lug | 92 |
| 9.5.4 Peripheral Electrical Component | 93 |
| 9.5.4.1 Circuit Breaker, Fuse, and Electromagnetic Contactor | 93 |
| 9.5.4.2 AC Input Reactor | 94 |
| 9.5.4.3 Output Reactors | 96 |
| 9.5.4.4 EMC Filter | 100 |
| 9.5.4.5 Magnetic Ring and Ferrite Clamp | 103 |
| 9.5.4.6 Braking Resistor | 105 |
| 10 Solutions to Common EMC Problems | 110 |
| 10.1 Earth Leakage Circuit Breaker Malfunction | 110 |

| | |
|---|-----|
| 10.2 Harmonic Suppression | 111 |
| 10.3 I/O Signal Interference | 111 |
| 10.3.1 High-Speed Pulse Interference | 111 |
| 10.3.2 Common I/O Signal Interference | 112 |
| 10.4 RS485 and CAN Communication Interference | 112 |
| 11 Certification and Standard Compliance | 114 |
| 11.1 Compliance List | 114 |
| 11.2 CE Certification | 114 |
| 11.2.1 Precautions for Compliance with European Standards | 114 |
| 11.2.2 Requirements for Compliance with EMC Directive | 114 |
| 11.2.3 Requirements for Compliance with the LVD | 116 |
| 12 Service and Support | 117 |

Fundamental Safety Instructions

Safety Precautions

- This chapter provides essential safety instructions for proper use of the equipment. Before operating the equipment, read through the guide and comprehend all the safety instructions. Failure to observe the safety precautions may result in serious injuries or death of personnel or device damage.
- "Danger", "Warning", and "Caution" items in this guide do not indicate all safety precautions that need to be followed; instead, they just supplement the safety precautions.
- Use this product in an environment that complies with the design specifications. Malfunction or component damage caused by improper usage is not covered by warranty.
- Inovance shall take no responsibility for any personal injuries or property damage caused by improper usage.

Safety Levels and Definitions

**危险**

Indicates that failure to comply with the notice can result in death or severe personal injuries.

**警告**

Indicates that failure to comply with the notice may result in death or severe personal injuries.

**注意**

Indicates that failure to comply with the notice may result in minor or moderate personal injuries or equipment damage.

General Safety Instructions

- Drawings in the guide are sometimes shown without covers or protective guards. Remember to install the covers or protective guards as specified first, and then perform operations in accordance with the instructions.
- The drawings in the guide are shown for illustration only and may be different from the product you purchased.
- Operators must take mechanical precautions to protect personal safety and wear protective equipment, such as anti-smashing shoes, safety clothing, safety glasses, protective gloves, and protective sleeves.

Unpacking



- Do not install the equipment if you find damage, rust, or signs of use on the equipment or accessories upon unpacking.
- Do not install the equipment if you find water seepage or missing or damaged components upon unpacking.
- Do not install the equipment if you find the packing list does not conform to the equipment you received.



- Check whether the packing is intact and whether there is damage, water seepage, dampness, and deformation before unpacking.
- Unpack the package by following the unpacking sequence. Do not strike the package violently.
- Check whether there is damage, rust, or injuries on the surface of the equipment and equipment accessories before unpacking.
- Check whether the package contents are consistent with the packing list before unpacking.

Storage and Transportation



- Large-scale or heavy equipment must be transported by qualified professionals using specialized hoisting equipment. Failure to comply may result in personal injury or equipment damage.
- Before hoisting the equipment, ensure the equipment components such as the front cover and terminal blocks are secured firmly with screws. Loosely-connected components may fall off and result in personal injuries or equipment damage.
- Never stand or stay below the equipment when the equipment is being hoisted by the hoisting equipment.
- When hoisting the equipment with a steel rope, ensure the equipment is hoisted at a constant speed without suffering from vibration or shock. Do not turn the equipment over or let the equipment stay hanging in the air. Failure to comply may result in personal injuries or equipment damage.

 注意

- Handle the equipment with care during transportation and mind your steps to prevent personal injuries or equipment damage.
- When carrying the equipment with bare hands, hold the equipment casing firmly with care to prevent parts from falling. Failure to comply may result in personal injuries.
- Store and transport the equipment based on the storage and transportation requirements. Failure to comply can result in equipment damage.
- Avoid storing or transporting the equipment in environments with water splash, rain, direct sunlight, strong electric field, strong magnetic field, and strong vibration.
- Avoid storing the equipment for more than three months. Long-term storage requires stricter protection and necessary inspections.
- Pack the equipment strictly before transportation. Use a sealed box for long-distance transportation.
- Never transport the equipment with other equipment or materials that may harm or have negative impacts on this equipment.

Installation 危險

- The equipment must be operated only by professionals with electrical knowledge. Non-professionals are not allowed.

 警告

- Read through the guide and safety instructions before installation.
- Do not install this equipment in places with strong electric or magnetic fields.
- Before installation, check that the mechanical strength of the installation site can bear the weight of the equipment. Failure to comply can result in mechanical hazards.
- Do not wear loose clothes or accessories during installation. Failure to comply may result in an electric shock.
- When installing the equipment in a closed environment (such as a cabinet or casing), use a cooling device (such as a fan or air conditioner) to cool the environment down to the required temperature. Failure to comply may result in equipment over-temperature or a fire.
- Do not retrofit the equipment.
- Do not fiddle with the bolts used to fix equipment components or the bolts marked in red.
- When this product is installed in a cabinet or terminal equipment, protective measures such as a fireproof enclosure, electrical enclosure, or mechanical enclosure must be provided. The IP rating must meet IEC standards and local laws and regulations.
- Before installing equipments with strong electromagnetic interference, such as a transformer, install a shielding equipment for the equipment to prevent malfunction.
- Install the equipment onto an incombustible object such as a metal. Keep the equipment away from combustible objects. Failure to comply will result in a fire.

 注意

- Cover the top of the equipment with a piece of cloth or paper during installation. This is to prevent unwanted objects such as metal chippings, oil, and water from falling into the equipment and causing faults. After installation, remove the cloth or paper on the top of the equipment to prevent over-temperature caused by poor ventilation due to blocked ventilation holes.
- Resonance may occur when the equipment operating at a constant speed executes variable speed operations. In this case, install the vibration-proof rubber under the motor frame or use the vibration suppression function to reduce resonance.

Wiring 危險

- Equipment installation, wiring, maintenance, inspection, or parts replacement must be performed only by professionals.
- Before wiring, cut off all the power supplies of the equipment, and wait for at least the time designated on the equipment warning label before further operations because residual voltage still exists after power-off. After waiting for the designated time, measure the DC voltage in the main circuit to ensure the DC voltage is within the safe voltage range. Failure to comply will result in an electric shock.
- Do not perform wiring, remove the equipment cover, or touch the circuit board with power ON. Failure to comply will result in an electric shock.
- Check that the equipment is grounded properly. Failure to comply can result in an electric shock.

 警告

- Do not connect the input power supply to the output end of the equipment. Failure to comply can result in equipment damage or even a fire.
- When connecting a drive to the motor, check that the phase sequences of the drive and motor terminals are consistent to prevent reverse motor rotation.
- Ensure that the cables used for wiring meet the diameter, shielding, and other relevant requirements, and that the shielding layer of the shielded cables is reliably grounded at a single terminal.
- After wiring is done, check that all cables are connected properly and no screws, washers or exposed cables are left inside the equipment. Failure to comply may result in an electric shock or equipment damage.

 注意

- Follow the proper electrostatic discharge (ESD) procedure and wear an anti-static wrist strap to perform wiring. Failure to comply may result in damage to the equipment or to the internal circuit of the product.
- Use shielded twisted pairs for the control circuit. Connect the shield to the grounding terminal of the equipment for grounding purpose. Failure to comply will result in equipment malfunction.

Power-on


危險

- Before power-on, check that the equipment is installed properly with reliable wiring and the motor can be restarted.
- Check that the power supply meets equipment requirements before power-on to prevent equipment damage or a fire.
- After power-on, do not open the cabinet door or protective cover of the equipment, touch any terminal, or disassemble any unit or component of the equipment. Failure to comply will result in an electric shock.


警告

- Perform a trial run after wiring and parameter setting to ensure the equipment operates safely. Failure to comply may result in personal injuries or equipment damage.
- Before power-on, check that the rated voltage of the equipment is consistent with that of the power supply. Failure to comply will result in a fire.
- Before power-on, check that no one is near the equipment, motor, or machine. Failure to comply may result in death or personal injuries.

Operation


危險

- The equipment must be operated only by professionals. Failure to comply will result in death or personal injury.
- Do not touch any connecting terminals or disassemble any unit or component of the equipment during operation. Failure to comply will result in an electric shock.


警告

- Do not touch the equipment casing, fan, or resistor with bare hands to feel the temperature. Failure to comply may result in personal injuries.
- Prevent metal or other objects from falling into the equipment during operation. Failure to comply may result in a fire or equipment damage.




Maintenance


危險

- Equipment installation, wiring, maintenance, inspection, or parts replacement must be performed only by professionals.
- Do not maintain the equipment with power ON. Failure to comply will result in an electric shock.
- Before maintenance, cut off all the power supplies of the equipment and wait for at least the time designated on the equipment warning label.
- In case of a permanent magnet motor, do not touch the motor terminals immediately after power-off because the motor terminals will generate induced voltage during rotation even after the equipment power supply is off. Failure to comply will result in an electric shock.




警告

- Perform routine and periodic inspection and maintenance on the equipment according to maintenance requirements and keep a maintenance record.

| Repair | |
|---|---|
|  危険 | <ul style="list-style-type: none"> • Equipment installation, wiring, maintenance, inspection, or parts replacement must be performed only by professionals. • Do not repair the equipment with power ON. Failure to comply will result in an electric shock. • Before inspection and repair, cut off all the power supplies of the equipment and wait for at least the time designated on the equipment warning label. |
|  警告 | <ul style="list-style-type: none"> • Submit the repair request according to the warranty agreement. • When the fuse is blown or the circuit breaker or earth leakage current breaker (ELCB) trips, wait for at least the time designated on the equipment warning label before power-on or further operations. Failure to comply may result in death, personal injury or equipment damage. • When the equipment is faulty or damaged, the troubleshooting and repair work must be performed by professionals that follow the repair instructions, with repair records kept properly. • Replace quick-wear parts of the equipment according to the replacement instructions. • Do not use damaged equipment. Failure to comply may result in death, personal injury, or severe equipment damage. • After the equipment is replaced, check the wiring and set parameters again. |
| Disposal | |
|  警告 | <ul style="list-style-type: none"> • Dispose of retired equipment in accordance with local regulations and standards. Failure to comply may result in property damage, personal injury, or even death. • Recycle retired equipment by observing industry waste disposal standards to avoid environmental pollution. |

Safety Labels

For safe equipment operation and maintenance, comply with the safety labels on the equipment. Do not damage or remove the safety labels. See the following table for descriptions of the safety labels.

| Safety Label | Description |
|--|---|
|   | <ul style="list-style-type: none"> • Read through the safety instructions before operating the equipment. Failure to comply may result in death, personal injuries, or equipment damage. • Do not touch the terminals or remove the cover with power ON or within 10 min after power-off. Failure to comply will result in an electric shock. |

1 Hardware Description

1.1 Product Overview

The MD600 series is a compact, general-purpose, and cost-effective AC drive for small automation equipment. Featuring ease of use and high reliability, it is mainly used to control and adjust speed of three-phase AC asynchronous motors. The drive is suitable for industries such as the crystalline silicon, lithium battery, carpentry, logistics, food and beverage, cable, machine tool, and packaging.



Figure 1-1 Product appearance

The AC drive has the following features:

- Cost-effective: Reduces equipment life cycle costs through technical innovation and enhanced experience design.
- Compact: 38% smaller than the previous generation; heat dissipation technology of the vapor chamber; reduces cabinet costs by multi-axis installation.
- Easy to use: Crimping terminals; communication networking with dual network ports; easy speed control through the keypad, saving labor costs for equipment commissioning.
- Reliable: Independent air duct; conformal coating on the drive board; intelligent fan; anti-rotation protection; slip start; stable running, reducing losses caused by stop.

1.2 Model and Nameplate


Model

MD600
S
-
4T
5R5
B

①
②
③
④
⑤

| | |
|--|--|
| <p>① Product name MD600: AC drive series</p> | <p>④ Output current (A) 1R6: 1.6 A 5R5: 5.5 A ... 013: 13 A Note: R represents the decimal point ".".</p> |
| <p>② Model S: RS485 model A: CAN model</p> | <p>⑤ Braking unit B: with the braking unit Null: without the braking unit</p> |
| <p>③ Voltage class (V) 4T: three-phase 380 V to 480 V 2S: Single-phase 200 V to 240 V</p> | <p>-</p> |

Nameplate description



MODEL: MD600S-4T5R5B
Certification

INPUT: 3PH AC 380-480V 6.7A 50/60Hz

OUTPUT: 3PH AC 0-480V 5.5A 0-590Hz 2.2kW

S/N: 0101CG364R700003

Address: No. 52, Tian'e Dang Road, Wuzhong District,
Suzhou 215104, P.R. China

Suzhou Inovance Technology Co., Ltd.

The nameplate is only for your reference.

Serial number descriptions

0101CG36
4
R
7
00003

①
②
③
④
⑤

| | |
|---|--|
| <p>① Internal code Product material code</p> | <p>④ Month 1: January 2: February 3: March ... C: December</p> |
| <p>② Manufacturer code 4: Suzhou Inovance</p> | <p>⑤ Lot number 00001: First 00002: Second 00003: Third ... Range: 00001 to 99999</p> |
| <p>③ Year R: 2023 S: 2024 Note: I/L/O/Q is not used.</p> | - |

1.3 Components




Figure 1-2 Product components

| No. | Name | Description |
|-----|----------------------------------|--|
| ① | LED display on the keypad | It displays the axis number, status, unit, and data. |
| ② | Keys on the keypad | It is used for operations through the operating panel. |
| ③ | Communication terminal (CN1/CN2) | - |

| No. | Name | Description |
|-----|-------------------------------------|--|
| ④ | Control circuit terminal (CN4) | It integrates the Modbus communication, analog input, analog output, digital input, digital output, 24 V power supply output, and 10 V power supply output signals. |
| ⑤ | Nameplate | It displays the product information. |
| ⑥ | DIP switch for termination resistor | DIP switch for Modbus/CAN communication termination resistor |
| ⑦ | Relay terminal (CN3) | Relay output terminal |
| ⑧ | R (L1)/S/T (L2)/PE input terminals | It is used to connect three-phase/single-phase AC input power supplies. R/S/T terminals are used to connect the three-phase power supply. L1/L2 terminals are used to connect the single-phase power supply, and PE is the protective earthing terminal. |
| ⑨ | Braking terminal | It is used to connect the braking resistor. |
| ⑩ | U/V/W/PE output terminals | U/V/W terminals are used to connect the three-phase motor, and PE is the protective earthing terminal. |
| ⑪ | Cooling fan | It is used for heat dissipation. |

1.4 Product Model List

The following table lists mapping between the product model and structure.

Table 1-1 Relationship between the product model and structure (RS485 version)

| Structure | Model (Three-Phase 380 V to 480 V) | Model (Single-Phase 200 V to 240 V) |
|-----------|--|---|
| T1 | MD600S-4T1R6(B) MD600S-4T2R3(B) MD600S-4T4R8(B) MD600S-4T5R5(B) | MD600S-2S2R8(B) MD600S-2S4R6(B) MD600S-2S7R5(B) |
| T2 | MD600S-4T9R5(B) MD600S-4T013(B) | MD600S-2S010(B) |

Table 1–2 Relationship between the product model and structure (CAN version)

| Structure | Model (Three-Phase 380 V to 480 V) | Model (Single-Phase 200 V to 240 V) |
|-----------|--|---|
| T1 | MD600A-4T1R6(B) MD600A-4T2R3(B) MD600A-4T4R8(B) MD600A-4T5R5(B) | MD600A-2S2R8(B) MD600A-2S4R6(B) MD600A-2S7R5(B) |
| T2 | MD600A-4T9R5(B) MD600A-4T013(B) | MD600A-2S010(B) |

1.5 System Connection

When using the AC drive to drive an asynchronous motor, a variety of electrical components must be installed on both input and output sides to ensure system safety and stability. The following figure shows the system composition.




Figure 1-3 System connection

Table 1-3 Descriptions of peripheral electrical components

| Name | Installation Position | Applicable Drive Model | Function |
|-----------------|-----------------------|------------------------|--|
| Circuit breaker | AC drive input side | All models | It is installed between the power supply and the AC drive input side. Circuit breaker for protection against short circuit: When overcurrent occurs on downstream devices, it cuts off the power supply to prevent incidents. Residual current device (RCD): The drive may generate high-frequency leakage current during running. To prevent electric shock which may cause a fire, select a proper RCD based on actual applications. |
| Fuse | AC drive input side | All models | It protects downstream semiconductor components in case of short circuit. |

| Name | Installation Position | Applicable Drive Model | Function |
|---------------------------------|---|------------------------|--|
| Electromagnetic Contactor | AC drive input side | All models | It is used to connect to or cut off the power supply of the AC drive. Do not use the contactor to power on or off the drive frequently (interval: at least one hour) or use the contactor to directly start the drive. |
| AC input reactor | AC drive input side | All models | It provides the following functions: <ul style="list-style-type: none"> ● Improves the power factor on the input side. ● Eliminates harmonics on the input side and prevents other devices from being damaged due to voltage waveform distortion. ● Eliminates input current unbalance caused by inter-phase unbalance. |
| EMC filter | AC drive input side | All models | It reduces the conduction and radiation interference generated by the AC drive to external devices. |
| Simple filter | AC drive input side | All models | It reduces the conduction and radiation interference generated by the AC drive to external devices. In addition, it decreases conduction interference flowing from the power supply to the AC drive and improves the anti-interference capacity of the AC drive. |
| Braking resistor | AC drive input side | All models | For an AC drive with the model name containing letter B, it has the built-in braking unit. After the braking resistor is connected to the braking unit, the braking resistor consumes regenerative energy during motor deceleration. |
| Output reactor | AC drive output side | All models | Generally, the AC drive generates much high-order harmonics on the output side. When a motor is far away from the AC drive, much distributed capacitance exists in the circuit. Certain harmonics may cause resonance in the circuit, which brings the following adverse effects: <ul style="list-style-type: none"> ● Degrades the motor insulation performance and damages the motor in the long run. ● Generates large leakage current and causes frequent AC drive protection trips. The output reactor can protect motor insulation and reduce bearing current, prolonging the service life of the motor. |
| Magnetic ring and ferrite clamp | AC drive input side or output side | All models | When installed on the input side, the magnetic ring can suppress the noise in the input power supply system of the drive. When installed on the output side, the magnetic ring can suppress interference generated by the AC drive to external devices and reduce the bearing current. |
| | Signal cable | All models | It improves the anti-interference performance of signals. |
| Motor | AC drive output side | All models | Select an applicable motor. |
| External operating panel | Connect the external operating panel to the CN2 port. | All models | LCD operating panel SOP-20-810 and LED operating panel MD-BP-M. |

Note: For selection of peripheral electrical devices, see "[Option Specifications](#)" on page 84.

2 Mechanical Design

2.1 Installation Environment

Table 2-1 Environment requirements

| Item | Requirement |
|--|--|
| Installation location | Indoors without direct sunlight, dust, corrosive gas, combustible gas, oil mist, water vapor, drip, or salt |
| Overvoltage category of the power grid | Overvoltage category III |
| Temperature | <p>Installation/Ambient temperature: -10°C to $+50^{\circ}\text{C}$. When the temperature ranges from -10°C to $+40^{\circ}\text{C}$, no derating is required. For temperature above 40°C, derate 1.5% for every additional 1°C. Storage/Transportation temperature: -20°C to $+60^{\circ}\text{C}$.</p> <ul style="list-style-type: none"> • For better reliability, use the AC drive in places without drastic temperature changes. • When installing the drive into an enclosed environment such as a control cabinet, use a cooling fan or air conditioner to keep the temperature of the inlet air below 50°C. Failure to comply will result in overheat or fire. • Install the AC drive on a flame-retardant surface, with sufficient clearance reserved for heat dissipation. • Take measures to prevent the AC drive from being frozen. |
| Humidity | Storage/Ambient humidity: $< 95\%$ RH, non-condensing |
| Environment | <p>Pollution degree 2 or below Install the drive in a location that meets the following descriptions:</p> <ul style="list-style-type: none"> • Free from direct sunlight, dust, corrosive gas, combustible or explosive gas, oil mist, water vapor, drip, or salt • Insusceptible to vibration (away from equipment that may generate strong vibration, such as a punch press) • Free from unwanted objects such as metallic dust, oil, and water that may enter the AC drive • Free from radioactive materials, combustible materials, hazardous gas and liquid, and salt corrosion • Away from combustible materials such as wood |
| Altitude | <ul style="list-style-type: none"> • 1000 m and below: derating is not required. • For altitudes above 1000 m, derate 1% for every additional 100 m. <p>The maximum altitude is 2000 m. If the altitude is higher than 2000 m, consult your Inovance agent or sales personnel.</p> |

| Item | Requirement |
|----------------------|--|
| Vibration resistance | <ul style="list-style-type: none"> Usage scenario: Test according to IEC 60068-2-6. Amplitude at 5 Hz to 8.4 Hz: 3.5 mm; acceleration at 8.4 Hz to 200 Hz: 1 g; 10 cycles/axis Transport scenario: Test according to IEC 60068-2-64. Power spectrum density at 5 Hz to 100 Hz: 0.01 g²/Hz; power spectrum density at 200 Hz: 0.001 g²/Hz; Grms: 1.14 g |
| Shock | Usage/transportation scenario: Test according to IEC 60068-2-27. Acceleration: 15 g; pulse width: 11 ms; 18 times in directions of three axes |

2.2 Installation Direction

Install the AC drive upright, as shown in the following figure. Do not lie the AC drive on its back or side, or install it in the upside-down direction.




Figure 2-1 Installation direction

2.3 Installation Tool Preparations

Mechanical installation tools

"Table 2-2 Tools for mechanical installation" on page 24 lists the tools for mechanical installation.

Table 2–2 Tools for mechanical installation

| Tool | Description |
|--|---|
| Electric drill with appropriate drilling bits | It is used to drill mounting holes on the mounting surface. |
| Phillips screwdriver and straight screwdriver (2.5 mm to 6 mm) | It is used to tighten or loosen screws. |
| Caliper or tape measure | It is used to measure the installation dimensions of the equipment. |
| Gloves | They are used to prevent static electricity during mechanical installation. |
| Screw | It is used to fix the equipment to the mounting surface. |
| Rail bracket | It is used to fix the drive onto the rail bracket. |

Screw

"Table 2–3 Specifications and quantity of screws" on page 24 lists the specifications and quantity of screws required for mechanical installation.

Table 2–3 Specifications and quantity of screws

| Installation Mode | Specification | Quantity (Unit: PCS) | Description |
|--------------------|--|----------------------|-------------------------------------|
| Backplate mounting | M4x12 cross recessed pan head SEMS screws (with flat washer and spring washer) | 2 | Used to fix the drive onto the wall |

Tools for wiring

When wiring the main circuit terminal, select an appropriate installation tool based on the terminal size.

Table 2–4 Wiring tools for main circuit terminals

| Structure | Recommended Fastener | Tool |
|-----------|----------------------|---------------------------------|
| T1 to T2 | Terminal | Cable stripper and cable pliers |

2.4 Cabinet Design

2.4.1 Cabinet Layout

Reserve sufficient clearance according to the power rating of the AC drive. The recommended installation methods of the MD600 include single-layer installation and multi-layer installation.

- When only a single device is installed, reserve sufficient clearance around the device, as shown in the following figure.




Figure 2-2 Clearance for installation of a single device

Table 2-5 Clearance for installation of a single device (three-phase 380 V to 480 V)

| Power Rating (kW) | Clearance (mm) | | |
|-------------------|----------------|---------------|--------------|
| 0.37 | $A1 \geq 20$ | $B1 \geq 100$ | $C1 \geq 80$ |
| 0.75 | $A1 \geq 20$ | $B1 \geq 100$ | $C1 \geq 80$ |
| 1.5 | $A1 \geq 20$ | $B1 \geq 100$ | $C1 \geq 80$ |
| 2.2 | $A1 \geq 20$ | $B1 \geq 100$ | $C1 \geq 80$ |
| 4 | $A1 \geq 20$ | $B1 \geq 120$ | $C1 \geq 80$ |
| 5.5 | $A1 \geq 20$ | $B1 \geq 120$ | $C1 \geq 80$ |

Table 2-6 Clearance for installation of a single device (single-phase 200 V to 240 V)

| Power Rating (kW) | Clearance (mm) | | |
|-------------------|----------------|---------------|--------------|
| 0.37 | $A1 \geq 20$ | $B1 \geq 100$ | $C1 \geq 80$ |
| 0.75 | $A1 \geq 20$ | $B1 \geq 100$ | $C1 \geq 80$ |
| 1.5 | $A1 \geq 20$ | $B1 \geq 100$ | $C1 \geq 80$ |
| 2.2 | $A1 \geq 20$ | $B1 \geq 120$ | $C1 \geq 80$ |

- When multiple devices are installed side by side, the minimum distance between two devices is shown below.




Figure 2-3 Side-by-side installation clearance

Table 2-7 Side-by-side installation clearance (three-phase 380 V to 480 V)

| Power Rating (kW) | Clearance (mm) | | | |
|-------------------|----------------|---------------|--------------|--------------|
| 0.37 | $A1 \geq 20$ | $B1 \geq 100$ | $C1 \geq 80$ | $D1 \geq 30$ |
| 0.75 | $A1 \geq 20$ | $B1 \geq 100$ | $C1 \geq 80$ | $D1 \geq 30$ |
| 1.5 | $A1 \geq 20$ | $B1 \geq 100$ | $C1 \geq 80$ | $D1 \geq 0$ |
| 2.2 | $A1 \geq 20$ | $B1 \geq 100$ | $C1 \geq 80$ | $D1 \geq 0$ |
| 4 | $A1 \geq 20$ | $B1 \geq 120$ | $C1 \geq 80$ | $D1 \geq 0$ |
| 5.5 | $A1 \geq 20$ | $B1 \geq 120$ | $C1 \geq 80$ | $D1 \geq 0$ |

Table 2-8 Side-by-side installation clearance (single-phase 200 V to 240 V)

| Power Rating (kW) | Clearance (mm) | | | |
|-------------------|----------------|---------------|--------------|--------------|
| 0.37 | A1 \geq 20 | B1 \geq 100 | C1 \geq 80 | D1 \geq 30 |
| 0.75 | A1 \geq 20 | B1 \geq 100 | C1 \geq 80 | D1 \geq 0 |
| 1.5 | A1 \geq 20 | B1 \geq 100 | C1 \geq 80 | D1 \geq 0 |
| 2.2 | A1 \geq 20 | B1 \geq 120 | C1 \geq 80 | D1 \geq 0 |

Note

- Three-phase 0.37 kW to 0.75 kW models and single-phase 0.37 kW models are naturally ventilated, whereas the rest models are air-cooled.
 - For the naturally-ventilated models, if they are installed side-by-side, a distance of at least 30 mm must be reserved between two adjacent models.
 - The air-cooled model supports side-by-side mounting without any space between two models.
-
- When devices are installed at different layers, the minimum distance between two layers is shown below.




Figure 2-4 Clearance for device installation at different layers

Table 2-9 Clearance for device installation at different layers (three-phase 380 V to 480 V)

| Power Rating (kW) | Clearance (mm) | | | | |
|-------------------|----------------|----------|---------|---------|---------|
| 0.37 | A1 ≥ 20 | B1 ≥ 100 | C1 ≥ 80 | D1 ≥ 30 | E1 ≥ 80 |
| 0.75 | A1 ≥ 20 | B1 ≥ 100 | C1 ≥ 80 | D1 ≥ 30 | E1 ≥ 80 |
| 1.5 | A1 ≥ 20 | B1 ≥ 100 | C1 ≥ 80 | D1 ≥ 0 | E1 ≥ 80 |
| 2.2 | A1 ≥ 20 | B1 ≥ 100 | C1 ≥ 80 | D1 ≥ 0 | E1 ≥ 80 |
| 4 | A1 ≥ 20 | B1 ≥ 120 | C1 ≥ 80 | D1 ≥ 0 | E1 ≥ 80 |
| 5.5 | A1 ≥ 20 | B1 ≥ 120 | C1 ≥ 80 | D1 ≥ 0 | E1 ≥ 80 |

Table 2-10 Clearance for device installation at different layers (single-phase 200 V to 240 V)

| Power Rating (kW) | Clearance (mm) | | | | |
|-------------------|----------------|----------|---------|---------|---------|
| 0.37 | A1 ≥ 20 | B1 ≥ 100 | C1 ≥ 80 | D1 ≥ 30 | E1 ≥ 80 |
| 0.75 | A1 ≥ 20 | B1 ≥ 100 | C1 ≥ 80 | D1 ≥ 0 | E1 ≥ 80 |
| 1.5 | A1 ≥ 20 | B1 ≥ 100 | C1 ≥ 80 | D1 ≥ 0 | E1 ≥ 80 |
| 2.2 | A1 ≥ 20 | B1 ≥ 120 | C1 ≥ 80 | D1 ≥ 0 | E1 ≥ 80 |

2.4.2 Product Dimensions




Figure 2-5 Outline dimensions and mounting dimensions of T1 to T2 models

Table 2–11 Outline dimensions and mounting dimensions of T1 to T2 models

| St- ru- ct- ur- e | Moun- ting Hole (mm/ inch) | Size (mm/inch) | | | | | | | | | | Mounting Hole Di- ameter (mm/ inch) | Weight (kg/lb) |
|-------------------------------|--|----------------|-----------------|------------|---------------|---------------|---------------|----------------|--------------|--------------|---------------|---|-------------------|
| | | W1 | W2 | H1 | H2 | H | H3 | H4 | H5 | H6 | W | | |
| T1 | 54.5 (2.15) | 30 (1.18) | 159.5 (6.28) | 5 (0.2) | 170 (6.69) | 160 (6.30) | 158 (6.22) | 17.5 (0.69) | 17 (0.67) | 60 (2.36) | 120 (4.72) | Ø5 (0.20) | 0.8 (1.76) |
| T2 | 62.5 (2.46) | 34 (1.34) | 159.5 (6.28) | 5 (0.2) | 170 (6.69) | 160 (6.30) | 158 (6.22) | 22 (0.87) | 24 (0.95) | 68 (2.68) | 140 (5.51) | Ø5 (0.20) | 1 (2.20) |

2.5 EMC Design

2.5.1 Electromagnetic Compatibility

Overview

Electromagnetic compatibility (EMC) means that a device or system can work normally in its electromagnetic environment and the device or system does not emit electromagnetic interference (EMI) that causes abnormal operation of other devices or systems in the environment.

Type

Electromagnetic compatibility performance of the drive includes two aspects: electromagnetic emission (EMI) and electromagnetic sensitivity (EMS). EMI includes radiated emission (RE) and conducted emission (CE).

- RE: interference signal emitted by the product through the port of the housing.
- CE: interference signal transmitted by the product through the cable.

Interference and Anti-interference

Electromagnetic compatibility is a system-level concept, which indicates that the product has certain anti-interference capabilities and does not seriously interfere with other devices.

2.5.2 EMC-Compliant Control Cabinet Design

To prevent electromagnetic interference in the cabinet, isolate interference sources from devices that may be interfered during installation. Divide a cabinet into multiple EMC compartments or use multiple cabinets based on the intensity of interference sources, and install each device in accordance with the following wiring principles.

Table 2-12 Wiring requirements

| No. | Wiring Requirement |
|-----|---|
| 1 | Install the control devices and drive devices into two separate cabinets. |
| 2 | If multiple cabinets are used, use grounding cables with a cross-sectional area of at least 16 mm ² to connect different cabinets, therefore realizing equipotential bonding between the cabinets. |
| 3 | Place the devices in different areas in the cabinet according to the device signal strength. |
| 4 | Carry out equipotential bonding for the devices in different areas of the cabinet. |
| 5 | Shield all communication (for example, RS485) and signal cables leading from the electrical cabinet. |
| 6 | Install the power supply input filter close to the cabinet input interface. |
| 7 | Spray each grounding point in the cabinet. |




Figure 2-6 Recommended wiring for the cabinet system

2.6 Heat Dissipation Design

2.6.1 Ventilation Requirements

Common heat dissipation methods include the following:

- Natural ventilation
- Forced air cooling

2.6.1.1 Air Duct Design

Heat dissipation design of the cabinet door

The cabinet is forcibly cooled by a built-in fan. Therefore, to ensure that enough cooling air enters the cabinet, open an air inlet with an appropriate size on the cabinet door. For details on the effective area of the air inlet, see ["2.6.1.2 Air Outlet and Inlet" on page 32](#). The air flows from bottom to top after being heated. Therefore, the cabinet air inlet must be at least 50 mm lower than the air inlet of the drive, as shown below.




Figure 2-7 Position of the cabinet air inlet

2.6.1.2 Air Outlet and Inlet

Air inlet

The effective area of the air inlet is the actual ventilation area instead of the gross opening area. The following table describes the minimum ventilation area of the cabinet air inlet after the drive is installed in the cabinet.


Table 2-13 Minimum ventilation area of the cabinet air inlet (three-phase 380 V to 480 V)

| Structure | Power (kW) | Quantity | Min. Ventilation Area of Air Inlet for Air-Cooled Cabinet (cm ²) |
|-----------|------------|----------|--|
| T1 | 0.37 | 1 | 20.5 |
| | 0.75 | 1 | 20.5 |
| | 1.5 | 1 | 16.2 |
| | 2.2 | 1 | 16.2 |
| T2 | 4 | 1 | 22 |
| | 5.5 | 1 | 22 |

Table 2-14 Minimum ventilation area of the cabinet air inlet (single-phase 200 V to 240 V)

| Structure | Power (kW) | Quantity | Min. Ventilation Area of Air Inlet for Air-Cooled Cabinet (cm ²) |
|-----------|------------|----------|--|
| T1 | 0.37 | 1 | 20.5 |
| | 0.75 | 1 | 16.2 |
| | 1.5 | 1 | 16.2 |
| T2 | 2.2 | 1 | 22 |

For example, on the plate shown in the following figure, the size of each hole is $C \times C$, and there are 9 holes. Therefore, the ventilation area of the air inlet is $9 \times C \times C$.



The preceding tables apply only to a single product. For a cabinet containing multiple products, calculate the total ventilation area by adding the ventilation area of each product.

For example, a cabinet contains the following units:

T1 model (single-phase 0.37 kW) + T1 model (single-phase 1.5 kW) + T2 model (single-phase 2.2 kW) + T1 model (three-phase 0.75 kW) + T1 model (three-phase 2.2 kW) + T2

model (three-phase 4 kW). Therefore, the minimum ventilation area of the cabinet air inlet should be $20.5 + 16.2 + 22 + 20.5 + 16.2 + 22 = 117.4 \text{ cm}^2$.

For the air inlet installed with a filtering net, the air inlet resistance increases substantially. In this case, the minimum ventilation area of the air inlet must be increased to 1.2 to 1.5 times the value listed in the preceding table. The ventilation area in the preceding tables refers to the actual through-hole area of the opening. The ventilation area is calculated by the following: opening area x opening rate.

Air outlet

To ensure sufficient heat dissipation of the drive, hot air in the cabinet must be exhausted to the outside. Use the active ventilation design for the cabinet.

Table 2–15 Minimum ventilation area of the cabinet air outlet (three-phase 380 V to 480 V)

| Structure | Power (kW) | Quantity | Min. Ventilation Area of Air Outlet for Air-Cooled Cabinet (cm ²) |
|-----------|------------|----------|---|
| T1 | 0.37 | 1 | 32.8 |
| | 0.75 | 1 | 32.8 |
| | 1.5 | 1 | 26 |
| | 2.2 | 1 | 26 |
| T2 | 4 | 1 | 35.5 |
| | 5.5 | 1 | 35.5 |


Table 2–16 Minimum ventilation area of the cabinet air outlet (single-phase 200 V to 240 V)

| Structure | Power (kW) | Quantity | Min. Ventilation Area of Air Outlet for Air-Cooled Cabinet (cm ²) |
|-----------|------------|----------|---|
| T1 | 0.37 | 1 | 32.8 |
| | 0.75 | 1 | 26 |
| | 1.5 | 1 | 26 |
| T2 | 2.2 | 1 | 35.5 |

Note

The effective area of the air outlet is the actual ventilation area instead of the gross opening area.

For example, on the plate shown in the following figure, the size of each hole is C x C, and there are 9 holes. Therefore, the ventilation area of the air inlet is $9 \times C \times C$.



The preceding tables apply to only a single product. For a cabinet containing multiple products, calculate the total ventilation area by adding the ventilation area of each product. For the air outlet installed with a filtering net, the air outlet resistance increases substantially. In this case, the minimum ventilation area of the air outlet must be increased to 1.2 to 1.5 times the value listed in the preceding table. The ventilation area in the preceding tables refers to the actual through-hole area of the opening. The ventilation area is calculated by the following: opening area x opening rate.

For example, a cabinet contains the following units:

T1 model (single-phase 0.37 kW) + T1 model (single-phase 1.5 kW) + T2 model (single-phase 2.2 kW) + T1 model (three-phase 0.75 kW) + T1 model (three-phase 2.2 kW) + T2 model (three-phase 4 kW). Therefore, the minimum ventilation area of the cabinet air outlet should be $32.8 + 26 + 35.5 + 32.8 + 26 + 35.5 = 188.6 \text{ cm}^2$. In the active air exhaust mode, a fan is installed on the top of the cabinet to draw hot air out of the cabinet. This is a commonly used ventilation mode. To ensure that the hot air can be exhausted to the outside, the total air volume of the fan cannot be smaller than that of all drives in the cabinet.

The following table lists the cooling air volume required by the AC drive.


Table 2-17 Cooling air volume (three-phase 380 V to 480 V)

| Structure | Power (kW) | Quantity | Max. Air Volume Q _{max} (CFM) of the Fan at the Top of the Cabinet |
|-----------|------------|----------|---|
| T1 | 0.37 | 1 | 0 |
| | 0.75 | 1 | 0 |
| | 1.5 | 1 | 22 |
| | 2.2 | 1 | 22 |
| T2 | 4 | 1 | 38 |
| | 5.5 | 1 | 38 |

Table 2-18 Cooling air volume (single-phase 200 V to 240 V)

| Structure | Power (kW) | Quantity | Max. Air Volume Qmax (CFM) of the Fan at the Top of the Cabinet |
|-----------|------------|----------|---|
| T1 | 0.37 | 1 | 0 |
| | 0.75 | 1 | 22 |
| | 1.5 | 1 | 22 |
| T2 | 2.2 | 1 | 38 |

The maximum air volume Qmax is the maximum value of the point where the fan P-Q curve meets the abscissa, as shown in the following figure.



The preceding tables apply to only a single product. When multiple products are installed in the cabinet, calculate the total air volume by adding the air volume of each product.

For example, a cabinet contains the following products: T1 model (single-phase 0.37 kW) + T1 model (single-phase 1.5 kW) + T2 model (single-phase 2.2 kW) + T1 model (three-phase 0.75 kW) + T1 model (three-phase 2.2 kW) + T2 model (three-phase 4 kW). Therefore, the minimum air volume of the cabinet fan should be $0 + 22 + 38 + 0 + 22 + 38 = 120$ CFM.

2.6.2 Fan Design

The MD600 fan is designed with a separate fan duct and supports forward and reverse rotation of the fan.

To select the fan, do the following:

1. Calculate the sum of cooling air volume required by all the devices based on "Table 2-17" on page 35 and "Table 2-18" on page 36.
2. Determine the maximum air volume (Qmax) of the cabinet fan.

- Determine the specification and quantity of the fan based on the maximum air volume (Q_{max}).

Where:

The maximum air volume of the cabinet is 1.3 to 1.5 times the sum of the cooling air volume.

The maximum air volume of the cabinet is 1.6 to 2.2 times the sum of the cooling air volume if mesh filters, shutters, or other components are installed at the cabinet air outlet.

Note

- The air volume of the selected fan cannot be smaller than the maximum air volume Q_{max} . If a single fan cannot meet this requirement, multiple fans can be used.
 - Install the fan in the correct air exhaust direction to ensure that air flows from inside to outside of the cabinet. Otherwise, hot air cannot be exhausted and the drive may be overheated or damaged.
-

Removing the fan

The MD600 fan can be removed without any tool.

Press and hold the four snap-fit joints around the fan to pull the fan out, as shown by ①.




Figure 2-8 Fan removal

Installing the fan

Align the fan terminal with the slot as shown in ① and push the fan toward the drive until the snap-fit joints are in the places.




Figure 2-9 Fan installation

Note

For RS485 and CAN models, single-phase 0.75 kW, 1.5 kW, and 2.2 kW AC drives, as well as three-phase 1.5 kW, 2.2 kW, 4 kW, and 5.5 kW AC drives provide one fan.

3 Electrical Design

3.1 Electrical Wiring Diagram

Wiring diagram for the MD600 (RS485 model)




Figure 3-1 Input terminals of three-phase/single-phase power supply

Wiring diagram for the MD600 (CAN model)




Figure 3-2 Input terminals of three-phase/single-phase power supply



- Signal interference may cause malfunctions. Therefore, keep the signal cable at least 20 cm away from the power cable and separately configure the input and output sides of the main circuit.
- Do not leave cuttings inside the drive while wiring. Failure to comply may result in errors, faults, and malfunctions.
- Keep the drive clean. Do not drop cuttings or dust into the drive while drilling mounting holes on the control cabinet.





3.2 Cable Preparations

During the electrical design phase, you need to prepare cables according to the cable list and cable preparation.

Cable list

The cable list mainly includes the cable type, name, and appearance, as shown in the following table.

Table 3-1 Cable list

| Type | Name | Appearance | Type | Name | Appearance |
|--------------------|-----------------|---|-----------------------|---------------|--|
| Main circuit cable | Power cable |  | Control circuit cable | Signal cable |  |
| | Grounding cable |  | | Network cable |  |

Cable preparation

To prepare the cable, do as follows:

1. Strip the cable rubber jacket according to the length requirements in the following figure.




Figure 3-3 Cable preparation 1

2. Make lugs for the U/V/W cable and grounding cable according to the following length requirements.




Figure 3-4 Cable preparation 2

3.3 Basic Electrical Safety Precautions

3.3.1 Selecting Power Supply Isolation Devices

Install a manually operated input isolation device between the AC power supply and the AC drive. Disconnecting the isolation device can cut off the power supply for safety during installation and maintenance.

EU

To comply with the EU guidelines, the isolation device must be one of the following types according to electrical safety standards for machinery equipment specified in EN60204-1:

- Isolation switch (EN 60947-3) of AC-23B
- Circuit breaker for isolation which complies with EN 60947-2

Other regions

The isolation device must comply with the applicable safety regulations.

3.3.2 Selecting Main Contactors

If the main contactor is used, the type (number of operation times under load) must be AC-1 and must be in accordance with IEC 60947-4. Select the contactor based on the rated voltage and current of the AC drive.

3.3.3 Short Circuit Protection

When the AC drive encounters an internal short circuit fault, the fuse used to protect the AC drive will prevent damage to the AC drive and the adjacent devices.

If the motor cable size is determined according to the rated current of the AC drive, the AC drive can protect the motor cable and motor in case of short circuit. No other protective equipment is required.

3.3.4 Selecting Motors

After power-on, the motor generates heat continuously due to thermal effect of the current. The heat is then dissipated to the surroundings. When the generated heat exceeds the dissipated heat, the motor temperature rises, which will burn the motor. The drive provides motor overload protection, but does not provide motor overheat protection. Therefore, use a motor with the overheat detection function.



Use the dedicated motor for the MD600 series AC drive. Failure to comply will result in short circuit due to aging of insulation.

3.3.5 Checking the Compatibility of the Motor and Drive

The AC drive can be used to drive one or multiple AC asynchronous induction motors simultaneously. According to AC voltage and motor load, select the motor capacity and drive model according to ["9.3 Electrical Specifications" on page 79](#).

3.3.6 Selecting Surge Protection Devices

The surge protection device (SPD) is installed on the input side of the AC drive to ensure that electrical systems and important electrical and electronic equipment are protected from damage caused by lightning overvoltage. The SPD is mainly used to limit transient overvoltage and operating overvoltage caused by lightning in power supply and signal systems. Lightning surges can be transmitted to the AC drive through the power supply or signal cable. When a lightning strike occurs, the ground potential increases, which may damage the drive. The induced voltage can be produced in the cable and loop when a pulse electromagnetic field is generated by a lightning strike on the building (or in the vicinity). Therefore, in addition to the external lightning protection measures such as the installation of lightning rods, down conductors, and grounding devices, you need to install an SPD. This is because the lightning rod, down conductor, and grounding device cannot prevent conduction of lightning induction surge along the cable and secondary lightning strike.

3.3.7 Requirements on Power Grid System Compatibility

When the power supply distribution system of the AC drive is an asymmetric grounding system or a floating ground system (IT system), remove the ground safety capacitor for grounding applications. Any phase voltage to ground of the asymmetric grounding system or floating ground system (IT system) may exceed the voltage of

the built-in filter and safety capacitor. Therefore, connecting to ground in this system will damage the AC drive.

To avoid risks or accidents, it is not recommended to use the AC drive in an asymmetric grounding system or in a floating ground system (IT system).

The AC drive supports only TN and TT star-type power grids under normal conditions. Other power grids are not supported. Contact Inovance technical service personnel if necessary.

3.4 Main Circuit Wiring

3.4.1 Introduction to Main Circuit Terminals

Terminal layout




Figure 3-5 Layout of main circuit terminals for T1 to T2 models

Terminal descriptions

Table 3-2 Descriptions of main circuit terminals for T1 to T2 models

| Terminal Mark | Terminal Name | Function Description |
|---------------|---|---|
| L1, L2 | Single-phase power supply input terminals | The terminals are used to connect to the power supply. L1 is connected to the live wire and L2 is connected to the neutral wire. |
| R, S, T | Input terminals of three-phase power supply | Used to connect the three-phase AC input power supply. |
| (+), BR | Braking resistor connection terminals | The terminals are used to connect to the braking resistor for three-phase models with the power rating of 2.2 kW and above and single-phase models with the power rating of 1.5 kW and above. |
| U, V, W | Output terminals | Used to connect the three-phase motor. |
| PE | Grounding terminal (PE) | Used for protective grounding. |

Terminal dimensions




Figure 3-6 Main circuit terminal dimensions (mm) of T1 models




Figure 3-7 Main circuit terminal dimensions (mm) of T2 models

3.4.2 Wiring Description of Main Circuit Terminals

The following rules apply to the wiring of the main circuit:

- Terminals BR, (-), and (+) are used to connect options. Avoid connecting these terminals to an AC power supply.
- To protect the main circuit, separate it from all surfaces that may come into contact with it and provide covers as required.
- The control circuit is the internal safety extra-low voltage (SELV) circuit, which must be insulated and isolated from other circuits. Make sure that the control circuit is connected to an external SELV circuit.
- Prevent foreign matters from entering the wiring part of the terminal block.
- Do not solder twisted conductors.

For main circuit cable specifications, see ["9.5.3.1 Main Circuit Cables" on page 89](#).

3.5 Control Circuit Wiring

3.5.1 Introduction to Control Circuit Terminals

Terminal layout

["Figure 3-8 " on page 47](#) shows the layout of control circuit terminals.




Figure 3-8 Layout of control circuit terminals

Terminal descriptions

Table 3-3 Descriptions of control circuit terminals

| External | Terminal Type | Transmission Information Type | Terminal Mark | Terminal Name | Function |
|----------|----------------------|---|---------------|--|--|
| CN1 | RJ45 | Modbus communication CAN Communication | - | Communication port | RS485 models: The RJ45 network port can be used to connect to the commissioning software of the drive through RS485 and cannot be used to connect to the operating panel separately. CAN models: The RJ45 network port supports CANopen/CANlink communication and can be used to connect the background software connection of the drive through RS485. |
| CN2 | RJ45 | Modbus communication CAN Communication | - | Communication port External operating panel interface | RS485 models: The RJ45 network port can be used to connect to the commissioning software of the drive through RS485. CAN models: The RJ45 network port supports CANopen/CANlink communication and can be used to connect to the commissioning software of the drive through RS485. In addition, only this RJ45 port can be used to connect to the external operating panel. |
| CN3 | 3-pin terminal block | Digital output | TA | Relay output | Common terminal T/A of external relay contact |
| | | | TB | Relay output | Normally closed (NC) terminal T/B of external relay contact |
| | | | TC | Relay output | Normally open (NO) terminal T/C of external relay contact |

| External | Terminal Type | Transmission Information Type | Terminal Mark | Terminal Name | Function |
|----------|-----------------------|-------------------------------|---------------|--|--|
| CN4 | 12-pin terminal block | DI/DO/AI/AO/RS485 | AI1 | Analog input terminal 1 | Voltage input of -10 V to +10 V or 0 V to 10 V or current input of 0 mA to 20 mA; 12-bit resolution; accuracy after correction: 0.3%; response time: < 2 ms Input impedance in the voltage input mode: 22 k Ω ; input impedance in the current mode: 500 Ω |
| | | | 10V | 10 V analog voltage output | Output voltage range: 10 V \pm 5% Maximum output current: 10 mA |
| | | | GND | Analog ground | Internally isolated from COM |
| | | | AO1 | Analog output terminal 1 (RS485 model) | Voltage output of 0 V to 10 V; 12-bit resolution; correction accuracy: 0.5%; maximum load output current in the voltage output mode: 2 mA; load impedance in the voltage output mode: 5 k Ω |
| | | | DO1 | Digital output terminal 1 (CAN model) | Photocoupler isolation; unipolar open collector output; maximum output frequency: 100 Hz It cannot be connected directly to the power supply. The pull-up resistor with the resistance set according to the load must be added. Output voltage range: 0 V to 24 V Output current range: 0 mA to 50 mA |
| | | | 485+ | RS485 communication signal + (RS485 model) | Positive RS485 communication signal; maximum speed supported by hardware: 115.2 kbps; maximum transmission distance at the baud rate of 9.6 kbps: 1 km |
| | | | DO2 | Digital output terminal 2 (CAN model) | Photocoupler isolation; unipolar open collector output; maximum output frequency: 100 Hz It cannot be connected directly to the power supply. The pull-up resistor with the resistance set according to the load must be added. Output voltage range: 0 V to 24 V Output current range: 0 mA to 50 mA |
| | | | 485- | RS485 communication signal - (RS485 model) | Negative RS485 communication signal |
| | | | DI5 | Digital input terminal 5 (CAN model) | Isolated sink/source programmable DI; input frequency: < 100 Hz The operating voltage ranges from 15 V to 30 V. The voltage lower than 5 V is invalid and the voltage higher than 15 V is valid. The input impedance is 3.61 k Ω . |
| | | | DI1 | Digital input terminal 1 | See DI5 above. |

| External | Terminal Type | Transmission Information Type | Terminal Mark | Terminal Name | Function |
|----------|---------------|-------------------------------|---------------|---|---|
| S | - | - | S1 | DIP switch for termination resistor for 485+/CANH communication | The DIP switch is disconnected by default. For details, see "Table 3-4 " on page 50 |
| | | | S2 | DIP switch for termination resistor for 485-/CANL communication | The DIP switch is disconnected by default. For details, see "Table 3-4 " on page 50 . |
| | | | S3 | Voltage/current mode switch for AI | The voltage mode is used by default. For details, see "Table 3-4 " on page 50 . |
| | | | S4 | DIP switch for OP to connect the internal 24 V or external power supply | OP is connected to the internal 24 V by default. For details, see "Table 3-4 " on page 50 . |

The following table describes DIP switches.

Table 3-4 DIP switch definitions

| Name | Function |
|------|--|
| S1 | ON: Termination resistor connected for RS485/CAN communication OFF: Termination resistor disconnected for RS485/CAN communication |
| S2 | ON: Termination resistor connected for RS485/CAN communication OFF: Termination resistor disconnected for RS485/CAN communication |
| S3 | ON: AI1 supports the current input mode (impedance: 500 Ω). OFF: AI1 supports the voltage input mode. |
| S4 | NC: OP is not connected. OFF: OP is connected to the internal 24V terminal. |

Note

- By default, the DIP switch is in the OFF position.
- To connect the termination resistor, set both S1 and S2 to ON.

3.5.2 Wiring Descriptions of Control Circuit Terminals

Precautions

I/O signals include analog input (AI), analog output (AO), digital input (DI), digital output (DO) and relay output signals. To avoid interference to the I/O signals, separate the I/O signal cables at least 20 cm away from the main circuit cables (R/S/T cables and U/V/W cables) and other power cables or power supply cables.

AI1 wiring

Weak analog signals are easy to suffer external interference. Therefore, route the analog cable away from the interference source and keep the cable length as short as possible (no longer than 20 m). In applications where the analog signal suffers severe interference, install a filter capacitor or ferrite magnetic core at the analog signal source.




Figure 3-9 AI wiring

To select the current input mode for AI1, set S3 to ON. In this case, the input resistance is $500\ \Omega$. The wiring is as follows.




Figure 3-10 Wiring of AI1 in the current input mode

DI1 to DI5 wiring



When the OP terminal is connected to the internal 24 V (DIP switch S4 set to 24V), do not short the COM and OP terminals. Otherwise, the internal 24 V power supply will be damaged.

- Sink wiring mode




Figure 3-11 Sink wiring mode

To use the internal 24 V power supply of the drive, which is the most commonly wiring method, set the DIP switch S4 to 24V (short the OP and 24V terminals), and connect the COM terminal of the drive to the 0V terminal of the external controller.

In the mode, the DI5 of different AC drives cannot be connected in parallel.

Otherwise, the DI may malfunction. If DI5 of different AC drives must be connected in parallel, connect the anode of a diode to the DI in series and the diode needs to satisfy the following requirement: $I_F > 40 \text{ mA}$ and $V_R > 40 \text{ V}$, as shown in ["Figure 3-12 Parallel connection of DI5 of multiple AC drives in the sink mode"](#) on page 53.





Figure 3-12 Parallel connection of DI terminals of multiple AC drives in the sink mode

- Source wiring mode



Source wiring mode when the external 24 V power supply is used

Figure 3-13 Source wiring mode

- In the source wiring mode, you can only use the external 24 V power supply. To use the external power supply, set the DIP switch S4 to NC (OP unconnected), connect the OP terminal of the AC drive to the 0V terminal of the external controller, and connect the anode of the 24 V external power supply to the DI through the control contact on the external controller.

DO wiring

When the DO needs to drive a relay, connect a snubber diode on both sides of the relay coil. Otherwise, the 24 VDC power supply may be damaged. Ensure that the driving capacity does not exceed 50 mA.




Figure 3-14 Wiring between DO and relay



Caution

Connect the snubber diode with the polarity placed correctly. Otherwise, the DO circuit will be damaged upon the DO output.

DO: Optocoupler isolation, bipolarity open collector output

Output voltage range: 0 V to 24 V

Output current range: 0 mA to 50mA

The DO is a single-polarity terminal and can be wired only in the following way.

The DO does not require the internal 24 V power supply.




Figure 3-15 DO connecting to external controller

Wiring of the relay output terminal

The inductive load (relay, contactor, and motor) causes voltage peak after the current is disconnected. To minimize the interference at cutoff, use a voltage dependent resistor (VDR) at the relay contact for protection and install absorption circuits such as VDRs, RC absorption circuits, and diodes on the inductive load, as shown in ["Figure 3-16 Anti-interference treatment for relay output terminals" on page 55](#).




Figure 3-16 Anti-interference treatment for relay output terminals

Note

- The power supply connected with the control circuit must use class 2 power supply; otherwise, the operation performance of the AC drive will be degraded.
- For control cable specifications, see ["9.5.3.2 Control Circuit Cable" on page 92](#).

3.6 Selection of Communication Cables

3.6.1 RS485 Communication Cable

Use a three-conductor shielded cable as the RS485 bus to connect to 485+, 485-, and GND terminals of the AC drive. Use the twisted pair cable to connect to the 485+ and 485- terminals and use the other cable to connect to the RS485 reference ground terminal GND. Connect the shield to the equipment ground. In the following figure, the left termination resistor is set by the DIP switch on the master. If the master does not have a built-in termination resistor, install an external termination resistor. The right termination resistor is also set by the DIP switch.




Figure 3-17 RS485 bus topology

The following table lists the maximum number of nodes and transmission distance supported by the standard RS485 circuit at different transmission rates.

Table 3-5 Transmission distance and number of nodes

| Transmission Distance (m) | Rate (kbps) | Number of Nodes | Cable Specification |
|---------------------------|-------------|-----------------|---------------------|
| 100 | 115.2 | 128 | 26AWG |
| 1000 | 19.2 | 128 | 26AWG |

3.6.2 CAN Communication Cable

Use the daisy chain mode for the CAN bus, as shown in the following figure. Use shielded twisted pair cables for the CAN bus, and use twisted pair cables for CANH and CANL signal cables. In the following figure, the left termination resistor is set by the DIP switch or an external termination resistor is installed. The right termination

resistor is also set by the DIP switch. Connect the CAN signal reference ground of all the nodes (up to 64 nodes) together.




Figure 3-18 CAN bus topology

The transmission distance of the CAN bus is directly related to the baud rate and the communication cable. The following table describes the relationship between the maximum bus length and the baud rate.

Table 3-6 Transmission distance and baud rate

| Transmission Distance (m) | Rate (kbps) | Number of Nodes | Cross Sectional Area (mm ²) |
|---------------------------|-------------|-----------------|---|
| 25 | 1000 | 64 | 0.205 |
| 95 | 500 | 64 | 0.34 |
| 560 | 100 | 64 | 0.5 |
| 1100 | 50 | 64 | 0.75 |

Routing precautions

● Requirements on main circuit routing

The power supply input cable of the AC drive and motor cable can generate strong electromagnetic interference. To avoid electromagnetic interference caused by long-distance parallel coupling between the strong disturbing cable and control circuit cable, ensure a distance longer than 20 cm between main circuit cables and signal cables when cabling. Main circuit cables include the input R/S/T cable, output U/V/W cable, DC bus, and braking cable. Signal cables include the I/O signal cable and communication cable.

Cable ducts must be in good connection and well grounded. Use aluminum cable ducts to ensure equipotentiality of the device. Connect the AC drive and motor to the system (machines or devices) properly. Protect all connections with spray coating and ensure good contact of conductive metal.




Figure 3-19 Cable layout

- **Requirements on cabling I/O signal cables**

I/O signals include analog input (AI), analog output (AO), digital input (DI), digital output (DO) and relay output signals. To avoid interference to the I/O signals, separate the I/O signal cables at least 20 cm from the main circuit cables (R/S/T cables and U/V/W cables) and other power cables or power supply cables.

Routing instructions

- **Routing disturbing cables and sensitive cables**

Route cables that transmit different types of signals through different routes. Separate the disturbing cables from sensitive cables by a distance of at least 20 cm. When two types of cables must be intersected, the intersection angle must be 90 degrees to avoid interference, as shown in the following figure.




Figure 3-20 Routing of disturbing cables and sensitive cables

- **Routing cables that transmit different types of signals**

Route cables that transmit different types of signals through different routes and separate different types of signals with equipotential signals. When routing cables that transmit the same type of signals, lay equipotential signal cables to the outer layers and lay equipotential bondings as many as possible in the middle if possible, as shown in the following figure.




Figure 3-21 Routing cables that transmit different types of signals

● **Routing multi-conductor cables**

For multi-conductor cables, use one cable to transmit one type of signals. To use one cable to transmit multiple types of signals, use a cable with internal conductor shields, as shown in the following figure.




Figure 3-22 Routing multi-conductor cables

If certain conductors in a multi-conductor cable are reserved or unused, connect these conductors to the equipotential bondings, as shown below.




Figure 3-23 Handling reserved or unused conductors of multi-conductor cables

- **Requirements on the wiring loop area**

For cables that transmit low-level sensor signals and shared cables that transmit relay signals, lay them close to each other to avoid the large loop area. Use twisted pair cables for analog signals. Lay digital signal cables close to each other.




Figure 3-24 Recommended wiring loop area

- **Laying multiple types of cables**

For cables of different types, route the cables along the equipotential metal plate. To enhance the internal EMC performance, separate different types of cables or separate cables with metal separators (recommended) in the same metal (zinc-iron or stainless steel) duct.




Figure 3-25 Laying multiple types of cables

- **Requirements on handing of shielded cables**

Minimize the length of the unshielded part of a shielded cable, and connect the shield to the nearest PE terminal. If the unshielded part is too long, the cable conductor is prone to signal interference. There is no dedicated PE terminal on the MD600 enclosure. In this case, connect the shield to an external PE terminal.




Figure 3-26 Requirements on handing of shielded cables

This section takes feeding of punch press as an example to describe a typical application of electrical design of the AC drive.

Background

Background information of the project is as follows:

- Basic information of the AC drive: Voltage of three-phase 380 V to 480 V; power of 2.2 kW; braking resistor required
- Application: Inovance PLC+HMI; RS485 communication
- I/O requirements: Four DIs to control start/stop, and forward/reverse rotation of the drive; reset upon fault; speed adjustment by external potentiometer connecting to the AI

Schematic diagram design of electrical cabinet

The following figure shows the schematic diagram of the electrical cabinet based on the background information of the project.




Figure 3-27 Schematic diagram

4 Shipment Check


Procedure

1. Open the package and check whether the drive is intact.



If the AC drive or other accessories are damaged, do not operate or install the damaged device.

2. Check whether the drive model is consistent with that on the delivery order.



3. Record the model and serial No.

5 Power Supply Compatibility Check

Check and ensure that the voltage of the mains power is compatible with the voltage of the AC drive power supply.

The following table describes the AC drive models and power supply voltage.

Table 5-1 AC drive models and power supply voltage

| Rated Voltage | AC Drive Model |
|-----------------------------|---|
| Three-phase 380 V to 480 V | MD600S/A-4T1R6 MD600S/A-4T2R3 MD600S/A-4T4R8 MD600S/A-4T5R5B MD600S/A-4T9R5B MD600S/A-4T013B |
| Single-phase 200 V to 240 V | MD600S/A-2S2R8 MD600S/A-2S4R6 MD600S/A-2S7R5B MD600S/A-2S010B |

Note

MD600S indicates the RS485 model, and MD600A indicates the CAN model.

6 Unpacking, Storage, and Transportation

Unpacking

1. Open the package of the AC drive (①).
2. Take out the cushion (②).
3. Take out the AC drive (③) and the accessory kit (④).




Figure 6-1 AC drive unpacking

Table 6-1 Unpacking list

| No. | Name |
|-----|------------------|
| ① | AC drive package |
| ② | Cushion |
| ③ | AC Drive |
| ④ | Accessory kit |

Storage



Store and transport the equipment as required to prevent damage.

- The drive must be stored in a clean and dry room, where the temperature ranges from -20°C and +60°C and temperature change rate is smaller than 1°C/min.
- Do not store or transport the drive in environments with water splash, rain, direct sunlight, strong electric field, strong magnetic field, and strong vibration.
- Do not expose the drive to the environment with moisture, high temperature, or strong sunlight for a long time.

- If the drive needs to be stored for a long period of time, cover it or take other appropriate measures to keep it from contamination and environmental influences.
- To store the drive, pack the drive with the original packing box provided by Inovance.
- Avoid storing the drive for more than three months. When the product needs to be stored for an extended period, take more strict protection and necessary inspection.
- The electrolytic capacitor will deteriorate after long-term storage. Therefore, switch on the AC drive once for at least 5 hours every 6 months. Increase the input voltage slowly to the rated value by using a voltage regulator. Contact Inovance for technical support if necessary.
- Pack the drive strictly before transportation. Use a sealed box for long-distance transportation.
- Never transport the drive with other equipment or materials that may harm or have negative impacts on the drive.

Transportation



Danger

- Large-scale or heavy equipment must be transported by qualified professionals using specialized hoisting equipment. Failure to comply may result in personal injuries or equipment damage.
 - Before hoisting the equipment, ensure the components such as the front cover and terminal block are secured firmly with screws. Loosely-connected components may fall off and result in personal injuries or equipment damage.
 - Never stand or stay below the equipment when the equipment is being hoisted by the hoisting equipment.
 - When hoisting the equipment with a steel rope, ensure the equipment is hoisted at a constant speed without suffering from vibration or shock. Do not turn the equipment over or let the equipment stay hanging in the air. Failure to comply may result in personal injuries or equipment damage.
 - When carrying the equipment with bare hands, hold the equipment casing firmly with care to prevent parts from falling. Failure to comply may result in personal injuries.
 - Handle the equipment with care during transportation and mind your steps to prevent personal injuries or equipment damage.
-

7 AC Drive Installation

7.1 Pre-installation Check

Complete the following inspection items before installation.

Table 7-1 Pre-inspection checklist

| No. | Item | Checked |
|-----|---|--------------------------|
| 1 | The installation position is mechanically strong enough to bear the weight of the AC drive. | <input type="checkbox"/> |
| 2 | The load-bearing capacity of the ground and the environment meet the installation requirements. | <input type="checkbox"/> |
| 3 | Sufficient clearance is reserved for heat dissipation, including for heat dissipation of other devices in the cabinet. | <input type="checkbox"/> |
| 4 | The mounting bracket (if needed) is made of flame-retardant material. | <input type="checkbox"/> |
| 5 | If the application site is exposed to metal dust, install the drive in an enclosed cabinet to isolate the drive from the metal dust. In this case, the space inside the cabinet needs to be as large as possible. | <input type="checkbox"/> |
| 6 | Before installing the AC drive, install the bottom mounting bracket in the cabinet and guide rails (optional), and prepare mounting beams with holes reserved to fix the AC drive. | <input type="checkbox"/> |
| 7 | Keep flammables or explosives away from the drive. | <input type="checkbox"/> |

7.2 Backplate Mounting


T1 models (three-phase 380-480 V: 0.37-2.2 kW; single-phase 200-240 V: 0.37-1.5 kW) and T2 models (three-phase 380-480 V: 4-5.5 kW; single-phase 200-240 V: 2.2 kW) support backplate mounting.

Prerequisites

Before installation, check that the installation tools and environment have been prepared. For details, see "[Mechanical Design](#)" on page 22. This section describes quick backplate mounting steps.

Procedure

1. Use a Phillips screwdriver to secure the M4x12 cross recessed pan head SEMS screw (with the flat washer and spring washer) on the upper right side of the drive, as shown in ①.
2. Repeat the previous step to fix the screw below the drive, as shown in ②.



7.3 Guide Rail Installation

Install the guide rail for T1 models (three-phase 380-480 V: 0.37-2.2 kW; single-phase 200-240 V: 0.37-1.5 kW). For T2 models (three-phase 380-480 V: 4-5.5 kW; single-phase 200-240 V: 2.2 kW), the guide rail is not required.

Prerequisites

- To install the AC drive with a guide rail, order the DIN guide rail (option). For details, see ["9.5.1 List of Options" on page 84](#).
- Before installation, check that the installation tools and environment have been prepared. For details, see ["Mechanical Design" on page 22](#). This section describes quick guide rail installation steps.

Procedure

1. Insert the guide rail latch into the slot at the bottom of the drive until it clicks into place, as shown in ①.

Figure ② shows that the guide rail is installed in place.

Scenario 1: The guide rail is not installed in the cabinet.

2. Use the straight screwdriver to pull the guide rail latch up slightly, as shown in ③.
3. Install the guide rail to the snap-fit joint on the drive, as shown in ④.
4. Press the guide rail latch down to the place to lock the guide rail, as shown in ⑤.

Scenario 2: The guide rail is installed in the cabinet.

5. Hold the drive at the fixing position, push the bottom of the drive in the direction of the arrow to the place to lock it to the snap-fit joint, as shown in ⑥.
6. Press the guide rail latch down to the place to lock the guide rail, as shown in ⑦.




Figure 7-1 Guide rail installation

7.4 Post-installation Check

After the installation is done, check the following items.

Table 7-2 Post-installation checklist

| No. | Item | Checked |
|-----|--|--------------------------|
| 1 | The ceiling height meets the minimum requirements for smooth ventilation. The air inlet and air outlet are free of obstruction and have sufficient space. Sufficient space is reserved for safe passing when the cabinet door is opened. | <input type="checkbox"/> |
| 2 | All contact protection devices (such as the guard plate) inside and outside the cabinet are installed. | <input type="checkbox"/> |

8 AC Drive Wiring

8.1 Pre-wiring Check

Check the following items before wiring.

Table 8-1 Pre-wiring checklist

| No. | Item | Checked |
|-----|--|--------------------------|
| 1 | Cables used during wiring comply with the requirements on the cross sectional area and the shield. | <input type="checkbox"/> |
| 2 | The device and the drive are grounded properly. | <input type="checkbox"/> |
| 3 | Proper electrostatic discharge (ESD) procedures are followed and antistatic wrist straps are worn. | <input type="checkbox"/> |

8.2 Main Circuit Wiring

Context

For details on main circuit terminals and control circuit terminals, see "[Electrical Design](#)" on page 39. This section describes quick control circuit wiring.

Procedure

1. Ground the AC drive.
2. Check the rated value of the circuit breaker or fuse.
3. Check whether the rated motor voltage is compatible with the AC drive voltage.
4. Connect the AC drive to the motor.
5. Connect the AC drive to the mains power.




Figure 8-1 Connection diagram for CAN models




Figure 8-2 Connection diagram for RS485 models

8.3 Post-wiring Check

After wiring is completed, check the following items and tick compliant items.

Table 8-2 Post-wiring inspection checklist

| No. | Item | Checked |
|-----|---|--------------------------|
| 1 | The power supply input cables are connected to the R, S, and T terminals (three-phase 380 V) or L1 and L2 terminals (single-phase 220 V). | <input type="checkbox"/> |
| 2 | The motor input cables are connected to the U, V, and W terminals. | <input type="checkbox"/> |
| 3 | The dimensions of the main circuit cables meet the requirements. | <input type="checkbox"/> |
| 4 | Heat-shrink tubes are applied to cable lug copper pipes and conductors of main circuit cables, and completely cover the cable conductors. | <input type="checkbox"/> |
| 5 | The motor output cable does not exceed 50 m. Otherwise, the carrier frequency needs to be reduced through A5-01. | <input type="checkbox"/> |
| 6 | The ground cables are connected correctly. | <input type="checkbox"/> |

| No. | Item | Checked |
|-----|---|--------------------------|
| 7 | The output terminals and control signal terminals are securely fastened. | <input type="checkbox"/> |
| 8 | The braking resistor and braking unit (if used) are connected correctly and have proper resistance. | <input type="checkbox"/> |
| 9 | The control circuit signal cables are shielded twisted pair cables. | <input type="checkbox"/> |
| 10 | The control circuit cables and main circuit power cables are routed separately. | <input type="checkbox"/> |
| 11 | There are no screws, gaskets, or exposed cables left inside the product. | <input type="checkbox"/> |

9 Specifications

9.1 List of Model Selection

See the following table for key specifications.

Table 9–1 Model selection

| Type | Model | Structure | Power | Rated Input Current | Rated Output Current | Product Code | Protocol | Cooling Method | Built-in Braking Unit | |
|-----------------------------------|------------------------------------|-----------|-------|---------------------|----------------------|--------------|---------------------|---------------------|-----------------------|--|
| Three-phase 380 V to 480 V | | | | | | | | | | |
| RS485 models | MD600S-4 T1R6 | T1 | 0.37 | 1.9 | 1.6 | 0101C431 | RS485 communication | Natural ventilation | Not supported | |
| | MD600S-4 T1R6B | T1 | | | | 0101CR53 | RS485 communication | Natural ventilation | Supported | |
| | MD600S-4 T2R3 | T1 | 0.75 | 2.8 | 2.3 | 0101C432 | RS485 communication | Natural ventilation | Not supported | |
| | MD600S-4 T2R3B | T1 | | | | 0101CR55 | RS485 communication | Natural ventilation | Supported | |
| | MD600S-4 T4R8 | T1 | 1.5 | 5.9 | 4.8 | 0101C522 | RS485 communication | Air cooling | No | |
| | MD600S-4 T4R8B | T1 | | | | 0101CR56 | RS485 communication | Air cooling | Supported | |
| | MD600S-4 T5R5 | T1 | 2.2 | 6.7 | 5.5 | 0101CR57 | RS485 communication | Air cooling | No | |
| | MD600S-4 T5R5B | T1 | | | | 0101C428 | RS485 communication | Air cooling | Supported | |
| | MD600S-4 T9R5 | T2 | 4 | 11.6 | 9.5 | 0101CR91 | RS485 communication | Air cooling | No | |
| | MD600S-4 T9R5B | T2 | | | | 0101C520 | RS485 communication | Air cooling | Supported | |
| | MD600S-4 T013 | T2 | 5.5 | 15.8 | 13 | 0101CR52 | RS485 communication | Air cooling | No | |
| | MD600S-4 T013B | T2 | | | | 0101C429 | RS485 communication | Air cooling | Supported | |
| | Single-phase 200 V to 240 V | | | | | | | | | |

Specifications

| Type | Model | Structure | Power | Rated Input Current | Rated Output Current | Product Code | Protocol | Cooling Method | Built-in Braking Unit |
|-----------------------------------|----------------|-----------|-------|---------------------|----------------------|--------------|---------------------|---------------------|-----------------------|
| RS485 models | MD600S-2 S2R8 | T1 | 0.37 | 6.2 | 2.8 | 0101C427 | RS485 communication | Natural ventilation | Not supported |
| | MD600S-2 S2R8B | T1 | | | | 0101CR67 | RS485 communication | Natural ventilation | Supported |
| | MD600S-2 S4R6 | T1 | 0.75 | 10.2 | 4.6 | 0101C523 | RS485 communication | Air cooling | No |
| | MD600S-2 S4R6B | T1 | | | | 0101CR68 | RS485 communication | Air cooling | Supported |
| | MD600S-2 S7R5 | T1 | 1.5 | 16.6 | 7.5 | 0101CR63 | RS485 communication | Air cooling | No |
| | MD600S-2 S7R5B | T1 | | | | 0101C524 | RS485 communication | Air cooling | Supported |
| | MD600S-2 S010 | T2 | 2.2 | 22.2 | 10 | 0101CR87 | RS485 communication | Air cooling | No |
| | MD600S-2 S010B | T2 | | | | 0101C521 | RS485 communication | Air cooling | Supported |
| Three-phase 380 V to 480 V | | | | | | | | | |

| Type | Model | Structure | Power | Rated Input Current | Rated Output Current | Product Code | Protocol | Cooling Method | Built-in Braking Unit |
|------------------------------------|----------------|-----------|-------|---------------------|----------------------|--------------|-------------------|---------------------|-----------------------|
| CAN models | MD600A-4 T1R6 | T1 | 0.37 | 1.9 | 1.6 | 0101C552 | CAN communication | Natural ventilation | Not supported |
| | MD600A-4 T1R6B | T1 | | | | 0101CR66 | CAN communication | Natural ventilation | Supported |
| | MD600A-4 T2R3 | T1 | 0.75 | 2.8 | 2.3 | 0101C554 | CAN communication | Natural ventilation | Not supported |
| | MD600A-4 T2R3B | T1 | | | | 0101CR58 | CAN communication | Natural ventilation | Supported |
| | MD600A-4 T4R8 | T1 | 1.5 | 5.9 | 4.8 | 0101C557 | CAN communication | Air cooling | No |
| | MD600A-4 T4R8B | T1 | | | | 0101CR60 | CAN communication | Air cooling | Supported |
| | MD600A-4 T5R5 | T1 | 2.2 | 6.7 | 5.5 | 0101CR61 | CAN communication | Air cooling | No |
| | MD600A-4 T5R5B | T1 | | | | 0101C558 | CAN communication | Air cooling | Supported |
| | MD600A-4 T9R5 | T2 | 4 | 11.6 | 9.5 | 0101CR92 | CAN communication | Air cooling | No |
| | MD600A-4 T9R5B | T2 | | | | 0101C560 | CAN communication | Air cooling | Supported |
| | MD600A-4 T013 | T2 | 5.5 | 15.8 | 13 | 0101CR64 | CAN communication | Air cooling | No |
| | MD600A-4 T013B | T2 | | | | 0101C553 | CAN communication | Air cooling | Supported |
| Single-phase 200 V to 240 V | | | | | | | | | |

| Type | Model | Structure | Power | Rated Input Current | Rated Output Current | Product Code | Protocol | Cooling Method | Built-in Braking Unit |
|------------|----------------|-----------|-------|---------------------|----------------------|--------------|-------------------|---------------------|-----------------------|
| CAN models | MD600A-2 S2R8 | T1 | 0.37 | 6.2 | 2.8 | 0101C551 | CAN communication | Natural ventilation | Not supported |
| | MD600A-2 S2R8B | T1 | | | | 0101CR69 | CAN communication | Natural ventilation | Supported |
| | MD600A-2 S4R6 | T1 | 0.75 | 10.2 | 4.6 | 0101C555 | CAN communication | Air cooling | No |
| | MD600A-2 S4R6B | T1 | | | | 0101CR70 | CAN communication | Air cooling | Supported |
| | MD600A-2 S7R5 | T1 | 1.5 | 16.6 | 7.5 | 0101CR62 | CAN communication | Air cooling | No |
| | MD600A-2 S7R5B | T1 | | | | 0101C556 | CAN communication | Air cooling | Supported |
| | MD600A-2 S010 | T2 | 2.2 | 22.2 | 10 | 0101CR88 | CAN communication | Air cooling | No |
| | MD600A-2 S010B | T2 | | | | 0101C559 | CAN communication | Air cooling | Supported |

9.2 Selection Instance

Selection Flow

The following figure shows the AC drive selection flow.




Figure 9-1 Selection flow

Example

The following procedure takes the MD600S-4T1R6 as an example.

1. The voltage range of the MD600S-4T1R6 is three-phase 380 V to 480 V.
2. The current of the MD600S-4T1R6 is 1.6 A.
3. The MD600S-4T1R6 supports RS485 communication.
4. The models of the peripheral devices of the MD600S-4T1R6, such as the AC input reactor, output reactor, and EMC filter are MD-ACL-10-5-4T, MD-OCL-5-1.44, and FN 3287-10-44-C28-R65, respectively.

9.3 Electrical Specifications

In the following tables, the rated power of the AC drive is measured under the following conditions:

- For three-phase 380 V to 480 V models, the rated power is measured at the input voltage of 400 VAC.
- For single-phase 200 V to 240 V models, the rated power is measured at the input voltage of 230 VAC.

Three-phase 380 V to 480 V

Table 9–2 Electrical specifications for T1 to T2 models (three-phase 380 V to 480 V)

| Item | | Specification | | | | | | |
|---------------------------|---|--|------|-----|------|------|------|--|
| Model: MD600S/A-4Txxxx(B) | | 1R6 | 2R3 | 4R8 | 5R5B | 9R5B | 013B | |
| Structure | | T1 | | | | | T2 | |
| Input | Rated input current (A) | 1.9 | 2.8 | 5.9 | 6.7 | 11.6 | 15.8 | |
| | Rated voltage/frequency | Three-phase 380 VAC to 480 VAC, 50/60 Hz | | | | | | |
| | Allowable voltage fluctuation range | -15% to +10%, or 323 VAC to 528 VAC | | | | | | |
| | Allowable frequency fluctuation range | ±5%, or 47.5 Hz to 63 Hz | | | | | | |
| | Capacity of power supply (kVA) | 1.6 | 2.3 | 4.9 | 5.6 | 9.6 | 13.1 | |
| Output | Power (kW) | 0.37 | 0.75 | 1.5 | 2.2 | 4 | 5.5 | |
| | Continuous output current (A) | 1.6 | 2.3 | 4.8 | 5.5 | 9.5 | 13 | |
| | Output voltage | Three-phase 0 V to input voltage | | | | | | |
| | Maximum output frequency | 599 Hz (edited by parameter) | | | | | | |
| | Carrier frequency | 0.5 kHz to 16.0 kHz (automatically adjusted according to the load characteristics) | | | | | | |
| | Overload capacity | Heavy load: 60s at 150% of the rated current continuously | | | | | | |
| Heat dissipation design | Thermal power consumption (W) | 25 | 31 | 57 | 65 | 100 | 149 | |
| | Exhaust air volume (CFM) | - | - | 12 | 12 | 19 | 19 | |
| Overvoltage class | OVCIll | | | | | | | |
| Pollution degree | PD2 | | | | | | | |
| IP rating | IP40 (IP20 for power supply distribution wiring and capacitor vent) | | | | | | | |
| Protection category | Class I | | | | | | | |
| Grid type | TN, TT, star type | | | | | | | |

Single-phase 200 V to 240 V

Table 9-3 Electrical specifications for T1 to T2 models (single-phase 200 V to 240 V)

| Item | | Specification | | | |
|---------------------------|---|--|------|------|------|
| Model: MD600S/A-2Sxxxx(B) | | 2R8 | 4R6 | 7R5B | 010B |
| Structure | | T1 | | | T2 |
| Input | Rated input current (A) | 6.2 | 10.2 | 16.6 | 22.2 |
| | Rated voltage/frequency | Single-phase 200 VAC to 240 VAC, 50/60 Hz | | | |
| | Allowable voltage fluctuation range | -15% to +10%, or 170 VAC to 264 VAC | | | |
| | Allowable frequency fluctuation range | ±5%, or 47.5 Hz to 63 Hz | | | |
| | Capacity of power supply (kVA) | 1.5 | 2.4 | 4 | 5.3 |
| Output | Power (kW) | 0.37 | 0.75 | 1.5 | 2.2 |
| | Continuous output current (A) | 2.8 | 4.6 | 7.5 | 10 |
| | Output voltage | Three-phase 0 V to input voltage | | | |
| | Maximum output frequency | 599 Hz (edited by parameter) | | | |
| | Carrier frequency | 0.5 kHz to 16.0 kHz (automatically adjusted according to the load characteristics) | | | |
| | Overload capacity | overload: 60s at 150% of the rated current continuously | | | |
| Heat dissipation design | Thermal power consumption (W) | 22 | 36 | 55 | 77 |
| | Exhaust air volume (CFM) | - | 12 | 12 | 19 |
| Overvoltage class | OVCIll | | | | |
| Pollution degree | PD2 | | | | |
| IP rating | IP40 (IP20 for power supply distribution wiring and capacitor vent) | | | | |
| Protection category | Class I | | | | |
| Grid type | TN, TT, star type | | | | |

9.4 Technical Specifications

Table 9-4 Technical specifications

| Item | | Specification |
|---------------------|--|---|
| Basic functions | Input frequency resolution | Digital setting: 0.01 Hz Analog setting: maximum frequency x 0.025% |
| | Control mode | Speed open loop control (V/f control) Open-loop vector control (SVC) |
| | Torque boost | Automatic torque boost; manual torque boost: 0.1 % to 100.0% |
| | V/f curve | Straight-line type, multi-point type, and V/f separation |
| | Acceleration/ Deceleration curve | Straight-line or S-curve acceleration/deceleration Four types of straight-line acceleration and deceleration time are supported. The first two types range from 0.0s to 6500.0s, and the last two types range from 0.00s to 650.00s. The S-curve acceleration/deceleration time ranges from 0.00s to 650.00s |
| | DC braking | Start frequency of DC braking: 0.00 Hz to 599 Hz Braking time: 0.0s to 100.0s Braking current: 0.0% to 100.0% |
| | Jog control | Frequency range: -50.00 Hz to +50.00 Hz Acceleration/deceleration time: 0.00s to 650.00s |
| | Running through simple PLC or multi-reference | The AC drive can implement up to 16 speeds by using the simple PLC function or control terminals. |
| | Built-in PID | The PID function facilitates the implementation of the closed-loop process control system. |
| | Automatic voltage regulation (AVR) | When the mains voltage changes, the output voltage keeps constant automatically. |
| | Overvoltage and overcurrent suppression control | This function limits the current and voltage automatically during operation to prevent frequent tripping caused by overvoltage/overcurrent. |
| Quick current limit | The function minimizes the occurrence of overcurrent to ensure normal operation of the AC drive. | |
| Customized function | Undervoltage suppression | The load feedback energy compensates for any voltage reduction upon an instantaneous power failure, allowing the AC drive to continue to operate for a short period. |
| | Virtual DI/DO | Five groups of virtual DIs/DOs are supported to implement simple logic control. |
| | Timing control | Time range: 0.0 minute to 6500.0 minutes |
| | Multiple fieldbuses | Modbus (Modbus RTU), CANlink, and CANopen buses are supported. |
| | Commissioning software | The software allows you to upload and download AC drive parameters and supports the virtual oscilloscope function. You can monitor the internal state of the AC drive through the virtual oscilloscope. |

| Item | | Specification |
|-----------------------------|--------------------------------------|---|
| Running | Operation command source | Operating panel, control terminal, and communication (switchable in multiple ways) |
| | Frequency reference | The drive supports 10 frequency reference sources, including digital setting, analog voltage, analog current, pulse setting, and communication (switchable in multiple ways). |
| | Auxiliary frequency source | The drive supports 10 auxiliary frequency reference sources. The auxiliary frequency reference can be used together with the main frequency reference to implement fine adjustment and frequency superposition. |
| | Input terminal | RS485 models: Four DIs, among which DI1 to DI3 are normal terminals and DI4 is a high-speed terminal (max. frequency of signal: 20 kHz); one AI, which supports voltage input of -10 V to +10 V or current input of 0 mA to 20 mA (switched via the DIP switch) CAN models: Five DIs, among which DI1 to DI3 and DI5 are normal terminals and DI4 is a high-speed terminal (max. frequency of signal: 20 kHz); one AI, which supports voltage input of -10 V to +10 V or current input of 0 mA to 20 mA (switched via the DIP switch). |
| | Output terminal | RS485 models: One dual-contact relay output terminal; contact driving capability: 250 VAC, 3 A, COS ϕ =0.4; one AO, which supports voltage output of 0 V to 10 V CAN models: Two normal DOs; one dual-contact relay output terminal; contact driving capability: 250 VAC, 3 A, COS ϕ =0.4 |
| Operating panel and display | LED Display | The LED displays parameters. |
| | LCD display | Optional and two languages (Chinese or English) available |
| | Parameter copy | It allows quick parameter copy through the LCD operating panel (optional). |
| | Key locking and function selection | The function can be used to lock the keys partially or completely and limit the availability of some keys to prevent accidental operation. |
| Protection functions | Phase loss protection | Input/output phase loss protection |
| | Instantaneous overcurrent protection | The drive stops when the output current reaches the overcurrent protection point. |
| | Overvoltage protection | The drive stops when the DC voltage of the main circuit is above 820 V (applicable to three-phase 380 V models). The drive stops when the DC voltage of the main circuit is above 410 V (applicable to single-phase 220 V models). |
| | Undervoltage protection | The drive stops when the DC voltage of the main circuit is lower than 350 V (applicable to three-phase 380 V models). The drive stops when the DC voltage of the main circuit is lower than 190 V (applicable to single-phase 220 V models). |
| | Overtemperature protection | Protection is triggered when the inverter bridge gets overheated. |
| | Overload protection | The drive stops 60s after operating at 150% of the rated current. |
| | Short circuit protection | Output phase-to-phase short circuit protection and output phase-to-ground short circuit protection |

| Item | | Specification |
|-------------|----------------------|--|
| Environment | Operating location | Indoors without direct sunlight, dust, corrosive gas, combustible gas, oil mist, water vapor, drip, or salt |
| | Altitude | Below or equal to 1000 m: derating not required; 1000 m < altitude ≤ 2000 m: de-rated by 1% for every additional 100 m; maximum altitude: 2000 m If the altitude is higher than 2000 m, consult your Inovance agent or sales personnel. |
| | Ambient temperature | -10°C to +50°C. 40°C to 50°C: de-rated by 1.5% for every additional 1°C. |
| | Humidity | Storage/Ambient humidity: <95% RH, non-condensing |
| | Vibration resistance | <ul style="list-style-type: none"> ● Usage scenario: Test according to IEC 60068-2-6. Amplitude at 5 Hz to 8.4 Hz: 3.5 mm; acceleration at 8.4 Hz to 200 Hz: 1 g; 10 cycles/axis ● Transport scenario: Test according to IEC 60068-2-64. Power spectrum density at 5 Hz to 100 Hz: 0.01 g²/Hz; power spectrum density at 200 Hz: 0.001 g²/Hz; Grms: 1.14 g |
| | Shock | Usage/transportation scenario: Test according to IEC 60068-2-27. Acceleration: 15 g; pulse width; 11 ms; 18 times in directions of three axes |
| | Storage temperature | -20°C to +60°C |

9.5 Option Specifications

9.5.1 List of Options

Optional peripherals include braking units and external operating panels, as listed in the following table. For use of each option, see its user guide. If any option is required, specify it in your order.



Table 9-5 Option list

| Type | Name | Option Model | Ordering Code | Applicable Drive Model | Function Description |
|--------------------------|-------------------------------|--|---------------|--|--|
| External operating panel | Hand-held LCD operating panel | SOP-20-810 | 01040028 | All models | The external LCD operation panel supports Chinese and English display, parameter copying, and connection to the commissioning software. |
| | Smart operating panel | MD-BP-M | 01040264 | All models | The external LED operating panel supports digital and English display, parameter setting, and status monitoring. |
| Cable | Main circuit cable | The recommended cable lug manufacturer is Zhejiang Kise. For details of recommended lugs, see "9.5.3.3 Cable Lug" on page 92 . | | | It is recommended that the input and output main circuit cables use symmetrical shielded cables. Compared with four-conductor cables, symmetrical shielded cables can reduce electromagnetic radiation in the whole transmission system. It is recommended that power cables also use symmetrical shielded cables. |
| | Control circuit cables | All control circuit cables must be shielded cables. Use a separate shielded cable for each type of analog signal. It is recommended that digital signal cables use shielded twisted pair (STP) cables. | | | |
| | Extension cable | MDCAB | 01013008 | All models | The standard 8-conductor network cable can be used to connect to the SOP-20-810 through the network port or connect to the commissioning software installed on the computer through the relay mode of the SOP-20-810. |
| Accessory | DIN guide rail | MD600-DGJ1 | 01040265 | Applicable only to T1 models (three-phase 380 V to 480 V: 0.37 kW to 2.2 kW; single-phase 200 V to 240 V: 0.37 kW to 1.5 kW) | DIN guide rail |
| | SOP-20-810 mounting base | CP600-BASE1 | 01040022 | All models | It is used to install the SOP-20-810 to the cabinet door. |

Note

For the list of peripheral electrical devices, see ["1.5 System Connection" on page 19](#).

9.5.2 Operating Panel

| Model | Description | Appearance |
|------------|--|--|
| SOP-20-810 | <p>SOP-20 is an LCD operating panel (optional) through which you can copy and download parameters. The LCD operating panel offers an easy way of parameter modification and displays information in Chinese and English. It is easy to use. For dimensions, see "Figure 9-2 Dimensions (unit: mm) of the SOP-20-810" on page 87 and "Figure 9-3 Mounting bracket dimensions and hole sizes (mm) of the SOP-20-810" on page 87.</p> |  <p>The image shows the SOP-20-810 LCD operating panel. It is a handheld device with a monochrome LCD screen displaying a menu for '1: Inverter' with options: '01 Parameters', '02 Fault Records', '03 Shortcut', and '04 Authority'. Below the screen, there are several control buttons: a 'Back' button, a 'Loc' button, a '10:00:00' timer display, and a 'Select' button. The central navigation area includes a circular directional pad with four arrow keys and a central 'OK' button. There are also two large function buttons, one green with a diamond icon and one red with a circle icon. At the bottom, there is a USB port.</p> |
| MD-BP-M | <p>It is an optional LED operating panel that supports parameter setting, parameter modification, and status monitoring. It can display digits and English letters for easy operation. For dimensions, see "Figure 9-5 Dimensions (unit: mm) of the cabinet door opening for mounting the MD-BP-M through the snap-fit joint" on page 88 and "Figure 9-6 Dimensions (unit: mm) of the cabinet door opening for mounting the MD-BP-M with screws" on page 89.</p> |  <p>The image shows the MD-BP-M LED operating panel. It is a smaller, square-shaped panel with a monochrome LED display. The display shows 'INVANCE' at the top, followed by '6720 684V' and a warning triangle icon. Below the display are several status indicators: 'r/min', 'Hz', 'A', 'V', and '%'. The control area includes a circular directional pad with four arrow keys and a central 'OK' button. There are also two large function buttons, one green with a diamond icon and one red with a circle icon.</p> |





Figure 9-2 Dimensions (unit: mm) of the SOP-20-810



Installation bracket dimensions

Hole dimensions

Figure 9-3 Mounting bracket dimensions and hole sizes (mm) of the SOP-20-810




Figure 9-4 Dimensions (unit: mm) of the MD-BP-M




Figure 9-5 Dimensions (unit: mm) of the cabinet door opening for mounting the MD-BP-M through the snap-fit joint




Figure 9-6 Dimensions (unit: mm) of the cabinet door opening for mounting the MD-BP-M with screws

9.5.3 Cable

9.5.3.1 Main Circuit Cables

Power cable selection requirements

For selection of power cables, follow national or regional regulations. Select IEC cables based on the following requirements:

- Compliant with IEC 60204-1 and IEC 60364-5-52 standards.
- PVC insulated cables with copper conductors
- Ambient temperature of 40°C and cable surface temperature of 70°C (Remark: When the ambient temperature exceeds 40°C, contact Inovance.)
- Symmetrical cable with copper mesh shield

If specifications of recommended cables for peripheral devices or options are outside the specification range of the cables applicable to the product, contact Inovance.

Use shielded cables to comply with the EMC requirements. The shielded cables are divided into three-conductor cables and four-conductor cables, as shown below. If the conductivity of the three-conductor cable shield cannot meet requirements, add an independent PE cable. Alternatively, use a four-conductor cable with one conductor as the PE cable. The shield of the shielded cable is comprised of coaxial

cooper braids to suppress radio frequency interference. To enhance the shielding performance and conductivity, the braided density of the shield must be greater than 90%.




Figure 9-7 Recommended power cable

Recommended cable

Table 9–6 Cable selection (three-phase 380 V to 480 V, compliant with CE certification)

| Three-phase 380 V to 480 V | | | | | | | | | | |
|----------------------------|------------|-------------------------|----------------------|---------------------|--|----------------------------|--|----------------------------|--|----------------------------|
| Drive Model | Power (kW) | Rated Input Current (A) | Rated Output Current | Braking Current (A) | R/S/T, U/V/W | | Grounding Cable | | Braking Terminal | |
| | | | | | Recommended Cable Specification (mm ²) | Recommended Terminal Model | Recommended Cable Specification (mm ²) | Recommended Terminal Model | Recommended Cable Specification (mm ²) | Recommended Terminal Model |
| MD600S/A-4T1R6(B) | 0.37 | 1.9 | 1.6 | 0.34 | 3x0.75 | E7510 | 0.75 | E7510 | 0.75 | E7510 |
| MD600S/A-4T1R6 | 0.37 | 1.9 | 1.6 | No braking | 3x0.75 | E7510 | 0.75 | E7510 | / | / |
| MD600S/A-4T2R3(B) | 0.75 | 2.8 | 2.3 | 0.7 | 3x0.75 | E7510 | 0.75 | E7510 | 0.75 | E7510 |
| MD600S/A-4T2R3 | 0.75 | 2.8 | 2.3 | No braking | 3x0.75 | E7510 | 0.75 | E7510 | / | / |
| MD600S/A-4T4R8(B) | 1.5 | 5.9 | 4.8 | 1.4 | 3x0.75 | E7510 | 0.75 | E7510 | 0.75 | E7510 |
| MD600S/A-4T4R8 | 1.5 | 5.9 | 4.8 | No braking | 3x0.75 | E7510 | 0.75 | E7510 | / | / |
| MD600S/A-4T5R5(B) | 2.2 | 6.7 | 5.5 | 2.05 | 3x0.75 | E7510 | 0.75 | E7510 | 0.75 | E7510 |
| MD600S/A-4T5R5 | 2.2 | 6.7 | 5.5 | No braking | 3x0.75 | E7510 | 0.75 | E7510 | / | / |
| MD600S/A-4T9R5(B) | 4 | 11.6 | 9.5 | 3.72 | 3x1.5 | E1512 | 1.5 | E1512 | 0.75 | E7510 |
| MD600S/A-4T9R5 | 4 | 11.6 | 9.5 | No braking | 3x1.5 | E1512 | 1.5 | E1512 | / | / |
| MD600S/A-4T013(B) | 5.5 | 15.8 | 13 | 5.12 | 3x2.5 | E2512 | 2.5 | E2512 | 0.75 | E7510 |

| Three-phase 380 V to 480 V | | | | | | | | | | |
|---|------------|-------------------------|----------------------|---------------------|--|----------------------------|--|----------------------------|--|----------------------------|
| Drive Model | Power (kW) | Rated Input Current (A) | Rated Output Current | Braking Current (A) | R/S/T, U/V/W | | Grounding Cable | | Braking Terminal | |
| | | | | | Recommended Cable Specification (mm ²) | Recommended Terminal Model | Recommended Cable Specification (mm ²) | Recommended Terminal Model | Recommended Cable Specification (mm ²) | Recommended Terminal Model |
| MD600S/A-4T013 | 5.5 | 15.8 | 13 | No braking | 3x2.5 | E2512 | 2.5 | E2512 | / | / |
| <p><1>: Chinese standards applicable; 3 x 4: one three-conductor cable with a cross sectional area of 4 mm². It is recommended to use the tube pre-insulated lugs (TG-JT type) produced by Zhejiang KISE Terminal Co., Ltd.</p> <p>1. Observe national or regional regulations during selection. The preceding table is based on the following: PVC insulation and copper conductor Ambient temperature of 40°C and cable surface temperature of 70°C (Remark: When the ambient temperature exceeds 40°C, contact Inovance.) Cable layout type E is adopted (see IEC 60204-1).</p> <p>2. If the conditions are different, you need to select the model according to actual conditions.</p> | | | | | | | | | | |

Table 9-7 Cable selection (single-phase 200 V to 240 V, compliant with CE certification)

| Single-phase 200 V to 240 V | | | | | | | | | | |
|---|------------|-------------------------|----------------------|---------------------|---|----------------------------|---|----------------------------|---|----------------------------|
| Drive Model | Power (kW) | Rated Input Current (A) | Rated Output Current | Braking Current (A) | R/S/T, U/V/W | | Grounding Cable | | Braking Terminal | |
| | | | | | Recommended Cable Specification (mm ²)<1> | Recommended Terminal Model | Recommended Cable Specification (mm ²)<1> | Recommended Terminal Model | Recommended Cable Specification (mm ²)<1> | Recommended Terminal Model |
| MD600S/A-2S2R8(B) | 0.37 | 6.2 | 2.8 | 0.71 | 3x0.75 | E7510 | 0.75 | E7510 | 0.75 | E7510 |
| MD600S/A-2S2R8 | 0.37 | 6.2 | 2.8 | No braking | 3x0.75 | E7510 | 0.75 | E7510 | / | / |
| MD600S/A-2S4R6(B) | 0.75 | 10.2 | 4.6 | 1.43 | 3x1 | E1010 | 1 | E1010 | 0.75 | E7510 |
| MD600S/A-2S4R6 | 0.75 | 10.2 | 4.6 | No braking | 3x1 | E1010 | 1 | E1010 | / | / |
| MD600S/A-2S7R5(B) | 1.5 | 16.6 | 7.5 | 2.87 | 3x2.5 | E2510 | 2.5 | E2510 | 0.75 | E7510 |
| MD600S/A-2S7R5 | 1.5 | 16.6 | 7.5 | No braking | 3x2.5 | E2510 | 2.5 | E2510 | / | / |
| MD600S/A-2S010(B) | 2.2 | 22.2 | 10 | 4.2 | 3x4 | E4012 | 4 | E4012 | 0.75 | E7510 |
| MD600S/A-2S010 | 2.2 | 22.2 | 10 | No braking | 3x4 | E4012 | 4 | E4012 | / | / |
| <p><1>: Chinese standards applicable; 3 x 4: one three-conductor cable with a cross sectional area of 4 mm². It is recommended to use the tube pre-insulated lugs (TG-JT type) produced by Zhejiang KISE Terminal Co., Ltd.</p> <p>1. Observe national or regional regulations during selection. The preceding table is based on: PVC insulation and copper conductor Ambient temperature of 40°C and cable surface temperature of 70°C (Remark: When the ambient temperature exceeds 40°C, contact Inovance.) Cable layout type E is adopted (see IEC 60204-1).</p> <p>2. If the conditions are different, you need to select the model according to actual conditions.</p> | | | | | | | | | | |

9.5.3.2 Control Circuit Cable

Note

Wire the control circuit cable according to EN 60204-1.

To prevent peripheral interference and noise, use shielded cables with the shield for control signal cables. Install a signal shield bracket at both ends of the shield to reliably connect the shield to the AC drive in 360°. Use separate shielded cables for different analog signals. It is recommended to use shielded twisted pair (STP) cables for digital signals.




Figure 9-8 Shielded twisted pair cable

Table 9-8 Specifications of the control circuit cable

| Structure | Terminal Type | Recommended IEC Cable Specification (mm ²) | Recommended Lug Specification |
|-----------|-------------------------|--|--|
| T1 | Control signal terminal | 0.5–1.0 | IEC: <ul style="list-style-type: none"> • 0.5 mm²(E0510) • 0.75 mm²(E7510) • 1 mm²(E1010) |
| | Relay terminal | 0.5–1.0 | |
| T2 | Control signal terminal | 0.5–1.0 | |
| | Relay terminal | 0.5–1.0 | |

9.5.3.3 Cable Lug

It is recommended to use the tube pre-insulated lugs (TG-JT type) produced by Zhejiang KISE Terminal Co., Ltd.




Figure 9-9 Appearance and dimensions of the tube pre-insulated lug (TG-JT type)

Table 9-9 Specifications and dimensions of the tube pre-insulated lug (TG-JT type)

| Cross Sectional Area | Model | Dimension (mm) | | | | | Insulation Sheath Color (1) For Germany (2) For France | Crimping Tool |
|-------------------------------|-------|----------------|------|-----|------|-----|--|---------------|
| | | F | L | W | DØ | CØ | | |
| 22AWG 0.5 mm ² | E0510 | 10.0 | 16.0 | 2.7 | 1.3 | 1.0 | (1) Orange (2) White | OPT AN-04WF |
| 20AWG 0.75 mm ² | E7510 | 10.0 | 16.0 | 2.8 | 1.5 | 1.2 | (1) White (2) Blue | OPT AN-04WF |
| 18AWG 1.0 mm ² | E1010 | 10.0 | 16.5 | 2.9 | 1.7 | 1.4 | (1) Yellow (2) Red | OPT AN-04WF |
| 16AWG 1.5 mm ² | E1510 | 10.0 | 16.5 | 3.5 | 2.0 | 1.7 | (1) Red (2) Black | OPT AN-04WF |
| | E1512 | 12.0 | 18.5 | 3.5 | 2.0 | 1.7 | (1) Red (2) Black | OPT AN-04WF |
| 14AWG 2.5 mm ² | E2510 | 10.0 | 17.5 | 4.1 | 2.6 | 2.3 | (1) Blue (2) Gray | OPT AN-04WF |
| | E2512 | 12.0 | 19.5 | 4.1 | 2.6 | 2.3 | (1) Blue (2) Gray | OPT AN-04WF |
| 12AWG 4.0 mm ² | E4012 | 12.0 | 19.5 | 4.5 | 3.15 | 2.8 | (1) Gray (2) Orange | OPT AN-10WF |

9.5.4 Peripheral Electrical Component

9.5.4.1 Circuit Breaker, Fuse, and Electromagnetic Contactor

The following tables list recommended circuit breakers, fuses, and electromagnetic contactors.

Table 9–10 Circuit breaker, fuse, and electromagnetic contactor (three-phase 380 V to 480 V, compliance with CE)

| Structure | Drive Model | Recommended Semiconductor Fuse Specification (Bussmann) | Recommended Contactor Specification (Schneider) | Minimum Specification of Recommended D-Type Circuit Breaker (Schneider) |
|-----------|-------------------|---|---|---|
| | | Rated Current (A) | Rated Current (A) | Rated Current (A) |
| T1 | MD600S/A-4T1R6(B) | 5 | 9 | 3 |
| | MD600S/A-4T2R3(B) | 5 | 9 | 4 |
| | MD600S/A-4T4R8(B) | 10 | 9 | 10 |
| | MD600S/A-4T5R5(B) | 15 | 9 | 10 |
| T2 | MD600S/A-4T9R5(B) | 20 | 12 | 16 |
| | MD600S/A-4T013(B) | 25 | 18 | 25 |

The recommended values in the preceding table are based on the following:

1. The ambient temperature of the device is 40°C and there is no forced air cooling method. The altitude is 2000 m. A single product is installed. The conductor carrying current density is 1.3 A/mm².
2. If the conditions are different, you need to select the model according to actual conditions.

Table 9–11 Circuit breaker, fuse, and electromagnetic contactor (single-phase 200 V to 240 V, compliance with CE)

| Structure | Drive Model | Recommended Semiconductor Fuse Specification (Bussmann) | Recommended Contactor Specification (Schneider) | Minimum Specification of Recommended D-Type Circuit Breaker (Schneider) |
|-----------|-------------------|---|---|---|
| | | Rated Current (A) | Rated Current (A) | Rated Current (A) |
| T1 | MD600S/A-2S2R8(B) | 10 | 9 | 10 |
| | MD600S/A-2S4R6(B) | 15 | 12 | 16 |
| | MD600S/A-2S7R5(B) | 25 | 18 | 25 |
| T2 | MD600S/A-2S010(B) | 35 | 25 | 32 |

The recommended values in the preceding table are based on the following:

1. The ambient temperature of the device is 40°C and there is no forced air cooling method. The altitude is 2000 m. A single product is installed. The conductor carrying current density is 1.3 A/mm².
2. If the conditions are different, you need to select the model according to actual conditions.

9.5.4.2 AC Input Reactor

The AC input reactor is mainly used to reduce harmonics in the input current. As an option, installing the input reactor on the input side of the AC drive can improve the input power factor, suppress the high harmonics of the input current of the AC drive, and reduce external conduction and radiation interference. When the application

environment has high requirements on grid harmonics suppression, you can choose an optional reactor as required.

Inovance AC input reactor

Recommended AC input reactor manufacturers and models are listed in the following tables.

$$\frac{\text{MD-ACL}}{\text{①}} - \frac{50}{\text{②}} - \frac{0.28}{\text{③}} - \frac{4T}{\text{④}} - \frac{2\%}{\text{⑤}}$$

Figure 9-10 AC input reactor model

| | | | |
|---|---|---|--|
| ① | Internal code MD-ACL: Inovance AC input reactor | ④ | Rated voltage 4T: 380 V |
| ② | Rated current 50: 50 A | ⑤ | Voltage drop percentage 2%: 2% |
| ③ | Inductance 0.28: 0.28 mH | - | |

Table 9–12 Selection of Inovance AC input reactors (three-phase 380 V to 480 V)

| Structure | Drive Model | Applicable Reactor | Inductance (mH) | Consumption (W) |
|-----------|-------------------|--------------------|-----------------|-----------------|
| T1 | MD600S/A-4T1R6(B) | MD-ACL-10-5-4T | 5 | - |
| | MD600S/A-4T2R3(B) | MD-ACL-10-5-4T | 5 | - |
| | MD600S/A-4T4R8(B) | MD-ACL-10-5-4T | 5 | - |
| | MD600S/A-4T5R5(B) | MD-ACL-10-5-4T | 5 | - |
| T2 | MD600S/A-4T9R5(B) | MD-ACL-15-3-4T | 3 | - |
| | MD600S/A-4T013(B) | MD-ACL-15-3-4T | 3 | - |

Dimensions




Figure 9-11 Dimensions of AC input reactors (10 A/15 A)

Table 9-13 Dimensions of AC input reactors (10 A/15 A, unit: mm)

| Model | A | B | C | D | E | F | G | H | I | J |
|----------------|-------|-----|-----|---|----|------|-------|----|-------|-------|
| MD-ACL-10-5-4T | 150±2 | 160 | 155 | 8 | 80 | 85±2 | 100±2 | 10 | 125±2 | Ø7x10 |
| MD-ACL-15-3-4T | 150±2 | 160 | 155 | 8 | 80 | 85±2 | 100±2 | 10 | 125±2 | Ø7x10 |

9.5.4.3 Output Reactors

With an output reactor installed on the output side of the drive, the excessive dV/dt can be reduced. This can reduce the voltage stress on the motor winding to protect it, lower the motor temperature, and prolong the service life of the motor. Whether to install an output reactor on the output side of the AC drive is dependent on the actual situation. The cable connecting the AC drive and motor cannot be too long. Otherwise, large distributed capacitance and high harmonics current will be caused. When the application environment has high requirements on grid harmonics suppression, you can choose an optional reactor as required.

Inovance AC output reactor

Models and dimensions of the recommended Inovance AC output reactors are as follows.

$$\frac{\text{MD-OCL}}{\text{①}} - \frac{50}{\text{②}} - \frac{0.14}{\text{③}} - \frac{4\text{T}}{\text{④}} - \frac{1\%}{\text{⑤}}$$

Figure 9-12 AC output reactor model

| | | | |
|---|--|---|--|
| ① | Internal code MD-OCL: Inovance AC output reactor | ④ | Rated voltage 4T: 380 V |
| ② | Rated current 50: 50 A | ⑤ | Voltage drop percentage 1%: 1% |
| ③ | Inductance 0.14: 0.14 mH | - | |

Table 9-14 Recommended models of the AC output reactor (three-phase 380-480 V)

| Structure | AC Drive Model | Rated Current (A) | Rated Power (kW) | Reactor Model | Inductance (mH) |
|-----------|-------------------|-------------------|------------------|----------------------|-----------------|
| T1 | MD600S/A-4T1R6(B) | 1.6 | 0.37 | MD-OCL-5-1.4-4T-1% | 1.4 |
| | MD600S/A-4T2R3(B) | 2.3 | 0.75 | MD-OCL-5-1.4-4T-1% | 1.4 |
| | MD600S/A-4T4R8(B) | 4.8 | 1.5 | MD-OCL-7-1.0-4T-1% | 1.0 |
| | MD600S/A-4T5R5(B) | 5.5 | 2.2 | MD-OCL-10-0.7-4T-1% | 0.7 |
| T2 | MD600S/A-4T9R5(B) | 9.5 | 4 | MD-OCL-15-0.47-4T-1% | 0.47 |
| | MD600S/A-4T013(B) | 13 | 5.5 | MD-OCL-15-0.47-4T-1% | 0.47 |

Table 9-15 Recommended models of the AC output reactor (single-phase 200-240 V)

| Structure | AC Drive Model | Rated Current (A) | Rated Power (kW) | Reactor Model | Inductance (mH) |
|-----------|-------------------|-------------------|------------------|----------------------|-----------------|
| T1 | MD600S/A-2S2R8(B) | 2.8 | 0.37 | MD-OCL-5-1.4-4T-1% | 1.4 |
| | MD600S/A-2S4R6(B) | 4.6 | 0.75 | MD-OCL-7-1.0-4T-1% | 1.0 |
| | MD600S/A-2S7R5(B) | 7.5 | 1.5 | MD-OCL-10-0.7-4T-1% | 0.7 |
| T2 | MD600S/A-2S010(B) | 10 | 2.2 | MD-OCL-15-0.47-4T-1% | 0.47 |

Dimensions

The following figures describe dimensions of the AC output reactor.




Figure 9-13 Dimensions of AC output reactors (5 A to 10 A)

Table 9-16 Dimensions of AC output reactors (5 A to 10 A, unit: mm)

| Model | A | B | C | G | F | I | J |
|---------------------|-------|-----|-----|------|------|------|-------|
| MD-OCL-5-1.4-4T-1% | 105±1 | 130 | 110 | 84±2 | 65±2 | 91±1 | Φ6x11 |
| MD-OCL-7-1.0-4T-1% | 105±1 | 130 | 110 | 84±2 | 65±2 | 91±1 | Φ6x11 |
| MD-OCL-10-0.7-4T-1% | 105±1 | 130 | 110 | 84±2 | 65±2 | 91±1 | Φ6x11 |




Figure 9-14 Dimensions of AC output reactors (15 A)

Table 9-17 Dimensions of AC output reactors (15 A, unit: mm)

| Model | A | B | C | G | F | I | J |
|----------------------|-------|-----|-----|------|------|------|-------|
| MD-OCL-15-0.47-4T-1% | 148±1 | 140 | 155 | 76±2 | 61±2 | 95±1 | Φ6x15 |




Figure 9-15 Dimensions of AC output reactors (20 A)

Table 9-18 Dimensions of AC output reactors (20 A, unit: mm)

| Model | A | B | C | G | F | I | J |
|----------------------|-------|-----|-----|------|------|------|-------|
| MD-OCL-20-0.35-4T-1% | 148±1 | 165 | 155 | 76±2 | 61±2 | 95±1 | Φ6x15 |

9.5.4.4 EMC Filter

To comply with the requirements of EN IEC 61800-3, install an external EMC filter listed in the following table. You can select FN 2090 and FN 3287 series EMC filters manufactured by Schaffner. Select the EMC filter according to the rated input current of the drive, as shown in the following table.

Note

If you need a filter of Schaffner, you can purchase it from the manufacturer.

Model selection

Table 9–19 Standard EMC filter model and appearance

| Filter Model | | Appearance |
|--------------|---------------|---|
| Schaffner | FN2090 series |  |
| | FN3287 series |  |

Table 9–20 Selection of EMC filters (three-phase 380 V to 480 V)

| Structure | Drive Model | Rated Current (A) | Applicable Filter |
|-----------|-------------------|-------------------|-----------------------|
| T1 | MD600S/A-4T1R6(B) | 1.6 | FN 3287-10-44-C28-R65 |
| | MD600S/A-4T2R3(B) | 2.3 | FN 3287-10-44-C28-R65 |
| | MD600S/A-4T4R8(B) | 4.8 | FN 3287-10-44-C28-R65 |
| | MD600S/A-4T5R5(B) | 5.5 | FN 3287-10-44-C28-R65 |
| T2 | MD600S/A-4T9R5(B) | 9.5 | FN 3287-16-44-C33-R65 |
| | MD600S/A-4T013(B) | 13 | FN 3287-16-44-C33-R65 |

Table 9-21 Selection of EMC filters (single-phase 200-240 V)

| Structure | Drive Model | Rated Current (A) | Applicable Filter |
|-----------|-------------------|-------------------|-------------------|
| T1 | MD600S/A-2S2R8(B) | 2.8 | FN 2090-8-06 |
| | MD600S/A-2S4R6(B) | 4.6 | FN 2090-10-06 |
| | MD600S/A-2S7R5(B) | 7.5 | FN 2090-16-06 |
| T2 | MD600S/A-2S010(B) | 10 | FN 2090-22-06 |

Dimensions

- Dimensions of Schaffner FN 2090 series filters




Figure 9-16 Dimensions of FN 2090 series filters (unit: mm)

Table 9-22 Dimensions of FN 2090 series filters (unit: mm)

| Rated Current (A) | A | B | C | D | E | F | G | H | I | J | K | L | M | N |
|-------------------|---------|--------|--------|------|------|-----|----|------|------|------|-----|-----|-----|-----------|
| 3 | 85 | 54 | 30.3 | 64.8 | 49.8 | 75 | 27 | 12.3 | 20.8 | 19.9 | 5.3 | 6.3 | 0.7 | 6.3 x 0.8 |
| 4 | | | | | | | | | | | | | | |
| 6 | | | | | | | | | | | | | | |
| 8 | 113.5±1 | 57.5±1 | 45.4±1 | 94±1 | 56 | 103 | 25 | 12.4 | 32.4 | 15.5 | 4.4 | 6 | 1 | 6.3 x 0.8 |

- Dimensions of Schaffner FN 3287 series filters




Figure 9-17 Dimensions of FN 3287 series filters (unit: mm)

Table 9-23 Dimensions of FN 3287 series filters (unit: mm)

| Rated Current (A) | A | B | C | D | E | F | G | H | J±2 | K | L±1 | M |
|-------------------|-----|----|-----|-----|-----|-----|----|-----|-----|----|-----|----|
| 10 | 180 | 40 | 112 | 153 | 0.8 | 170 | 20 | 4.5 | 94 | 11 | 68 | M5 |
| 16 | 200 | 45 | 112 | 170 | 0.8 | 185 | 25 | 5.4 | 102 | 11 | 76 | M5 |
| 25 | 205 | 45 | 132 | 173 | 0.8 | 190 | 25 | 5.4 | 113 | 13 | 83 | M5 |

Note

If you need an EMC filter of Schaffner, you can purchase it from the manufacturer.

9.5.4.5 Magnetic Ring and Ferrite Clamp

Model selection

The magnetic ring can be used on the input or output side of the AC drive. Install it as close to the AC drive as possible. When installed on the input side, the magnetic ring can suppress the noise in the input power supply system of the drive. When installed on the output side, the magnetic ring can suppress interference generated by the AC drive to external devices and reduce the bearing current.

In applications with leakage current and signal cable interference, install a magnetic ring or a ferrite clamp.

- Amorphous magnetic ring: featuring high permeability when the frequency is within 1 MHz and excellent anti-interference performance, but not as low-cost as the ferrite clamp

- Ferrite clamp: featuring high permeability when the frequency is above 1 MHz and excellent suppression performance on interference generated by low-power drives and signal cables

DY644020H, DY805020H, and DY1207030H are all amorphous magnetic rings.

Table 9–24 Appearance and models of the magnetic ring and ferrite clamp

| Type | Model | Appearance |
|---------------|------------|--|
| Magnetic ring | DY644020H |  |
| | DY805020H |  |
| | DY1207030H |  |
| Ferrite clamp | DYR-130-B |  |

Dimensions




Figure 9-18 Dimensions of the magnetic ring

Table 9-25 Dimensions of the magnetic ring

| Model | Dimension (OD x ID x HT) (mm) |
|------------|-------------------------------|
| DY644020H | 64 x 40 x 20 |
| DY805020H | 80 x 50 x 20 |
| DY1207030H | 120 x 70 x 30 |





Figure 9-19 Ferrite clamp dimensions (unit: mm)

9.5.4.6 Braking Resistor

Braking resistor protection

In applications where a braking resistor is installed, it is recommended to use a resistor with a temperature switch to ensure safety and avoid overheating and

burning of the braking resistor. Connect the temperature switch output to the electromagnetic contactor control circuit on the front end of the AC drive (as shown in the following figure) to implement the interlock protection function. When the resistor overheats, a tripping fault occurs, avoiding the resistor to be burned.



Resistance of braking resistors

The internal braking unit of the AC drive processes the regenerative energy generated by the motor during deceleration. When the voltage of the DC bus exceeds the limit set by the software, the braking unit automatically turns on and connects the braking resistor to the DC bus. The braking resistor consumes the regenerative energy to keep the bus voltage within the safe range. The braking resistor is disconnected until the bus voltage drops below a certain range. The resistance of the braking resistor is calculated by the following formula:

$$R = \frac{U_{BR}^2}{P_{BR}} = \frac{U_{BR}^2}{P_N \cdot k \cdot \eta_{motor} \cdot \eta_{inverter}}$$

Note

When the braking power is fed back from the motor to the U/V/W cable, and then fed back from the U/V/W cable to the DC bus of the drive, the braking power will be derated by the motor efficiency and the drive efficiency, respectively. Therefore, the braking power actually consumed by the braking resistor will be lower. The conversion coefficient is roughly estimated to be from 0.8 to 0.9.

R: Resistance of the braking resistor

U_{BR} : AC drive starting braking voltage (three-phase 380 V to 480 V models: 760 V by default; single-phase 200 V to 240 V models: 370 V by default; the default values can be modified.)

P_{BR} : Braking power that needs to be consumed by the braking resistor on the DC bus of the drive

P_n : Rated power of the AC drive

k: Multiple of the braking torque to the rated torque. Generally, it is set to 1.25 or around. The k value can be adjusted according to the actual situation.

η_{motor} : Motor efficiency. It is generally set to 0.85 or around or the actual motor efficiency. It can also be estimated by reference to the efficiency of the four-pole motor energy efficiency class IE3 specified in the IEC 60034-30-2 standard.

$\eta^{Inverter}$: It is generally set to 0.98 or around.

Power of braking resistors

In theory, the power of the braking resistor and the braking power are the same. However, because the braking resistor is naturally ventilated in the power supply distribution cabinet, power derating must be applied. Assume that the derating coefficient is α . You can select the rated power of the braking resistor according to the following formula:

$$P = \frac{P_{BR} \times D}{\alpha}$$

P: Rated power of the braking resistor

α : Power derating value of the braking resistor. It is generally about 50%. Depending on the type and the actual cooling conditions of the resistor, a higher derating value is required if the temperature of the resistor rises. Otherwise, a fire caused by overheating of the resistor may occur. Therefore, select the power according to the actual situation.

D: Braking frequency, that is, percentage of the regenerative process to the whole working process.

Braking frequency (D) is determined by application. The following table lists the typical braking frequency in different applications.

| Application | Elevator | Winding/ Unwinding Machine | Centrifuge | Occasional Braking Load | Regular Application |
|-------------------|------------|----------------------------------|------------|----------------------------|------------------------|
| Braking frequency | 20% to 30% | 20% to 30% | 50% to 60% | 5% | 10% |

Table 9–26 Selection of braking resistors (three-phase 380-480 V)

| Structure | AC Drive Model | Applicable Motor (kW) | Braking Unit | Recommended Braking Resistor Specification (125% of Braking Torque, ED: 10% ; Max. 10s) | Quantity of Braking Resistors | Minimum Braking Resistance (Ω) | Remarks |
|-----------|--------------------|-----------------------|--------------------|---|-------------------------------|---|---|
| T1 | MD600S/A-4T1R6(B) | 0.37 | Built-in, standard | 80 W/1450 Ω | 1 | 69 | AC drive model with the model name containing B |
| | MD600S/A-4T2R3(B) | 0.75 | | 140 W/800 Ω | 1 | 69 | |
| | MD6000S/A-4T4R8(B) | 1.5 | | 300 W/380 Ω | 1 | 69 | |
| | MD600S/A-4T5R5B(B) | 2.2 | | 440 W/250 Ω | 1 | 69 | |
| T2 | MD600S/A-4T9R5(B) | 4 | | 800 W/130 Ω | 1 | 41 | |
| | MD600S/A-4T013(B) | 5.5 | | 1100 W/100 Ω | 1 | 41 | |

Table 9–27 Selection of braking resistors (single-phase 200-240 V)

| Structure | AC Drive Model | Applicable Motor (kW) | Braking Unit | Recommended Braking Resistor Specification (125% of Braking Torque, ED: 10% ; Max. 10s) | Quantity of Braking Resistors | Minimum Braking Resistance (Ω) | Remarks |
|-----------|-------------------|-----------------------|--------------------|---|-------------------------------|---|---|
| T1 | MD600S/A-2S2R8(B) | 0.37 | Built-in, standard | 90 W/300 Ω | 1 | 52 | AC drive model with the model name containing B |
| | MD600S/A-2S4R6(B) | 0.75 | | 160 W/170 Ω | 1 | 52 | |
| | MD600S/A-2S7R5(B) | 1.5 | | 300 W/90 Ω | 1 | 52 | |
| T2 | MD600S/A-2S010(B) | 2.2 | | 440 W/60 Ω | 1 | 26 | |

Note

- The braking resistance in the preceding table is calculated based on the braking usage rate (ED) of 10% and the longest time for single braking of 10s.
 - The default initial braking voltages of built-in braking units for the 380-480 V models and 200-240 V models are 760 V and 370 V, respectively.
 - The data in the preceding table is only for reference. You can select the resistance and power of the braking resistor as required. (Note that the resistance cannot be lower than the recommended minimum value, whereas the power can exceed or be equal to the recommended value.) Select the braking resistor based on the generation power of the motor in the actual system, system inertia, deceleration time, and potential energy load.
 - Larger system inertia requires shorter deceleration time and more frequent braking. In this case, select a braking resistor with a higher power rating and lower resistance.
-

10 Solutions to Common EMC Problems

10.1 Earth Leakage Circuit Breaker Malfunction

When the earth leakage circuit breaker (ELCB) malfunctions, perform troubleshooting according to the following table.

Table 10–1 Troubleshooting when the ELCB malfunctions

| Trip | Possible Cause | Solution |
|-----------------------|--|--|
| Trip upon power-on | The anti-interference performance of the ELCB is poor. | <ol style="list-style-type: none"> 1. Use an ELCB of a recommended brand. 2. Use an ELCB with a higher tripping current. 3. Move the unbalanced load to the front end of the ELCB. |
| | The action current of the ELCB is too low. | |
| | Unbalanced load is connected to the rear end of the ELCB. | |
| | The capacitance to the ground at the front end of the AC drive is large. | |
| Trip during operation | The anti-interference performance of the ELCB is poor. | <ol style="list-style-type: none"> 1. Use an ELCB of a recommended brand. 2. Install a simple filter on the input side of the drive, and wind the LN/RST cables through a magnetic ring near the ELCB, as shown in <i>"Figure 10–1 Installing a simple filter and magnetic ring on the input side" on page 111.</i> 3. Use an ELCB with a higher rated tripping current. 4. Reduce the carrier frequency while ensuring performance. 5. Use shorter motor cables. |
| | The action current of the ELCB is too low. | |
| | Unbalanced load is connected to the rear end of the ELCB. | |
| | For motor cables and the motor, the distributed capacitance to ground is too high. | |




Figure 10-1 Installing a simple filter and magnetic ring on the input side

10.2 Harmonic Suppression

To suppress high-order harmonics of the drive and improve the power factor, install an AC input reactor on the input side of the drive to meet standard requirements.

10.3 I/O Signal Interference

10.3.1 High-Speed Pulse Interference

In the case of interference, take the following rectification measures.

| No. | Step |
|-----|--|
| 1 | Use shielded twisted pair cables and ground the cables at both ends. |
| 2 | Connect the motor housing to the PE terminal of the AC drive. |
| 3 | Connect the PE terminal of the AC drive to that of the power grid. |
| 4 | Add an equipotential bonding grounding cable between the host controller and the AC drive. |

| No. | Step |
|-----|---|
| 5 | Separate signal cables from power cables with a distance of at least 20 cm. |
| 6 | Add a ferrite clamp to the signal cable, or add a magnetic ring and wind the signal cable through the magnetic ring for one to two turns. |
| 7 | Install a magnetic ring to the U, V, and W output cables at the drive side and wind the cables through the magnetic ring for two to four turns. |
| 8 | Use a shielded power cable and properly ground its shield. |

10.3.2 Common I/O Signal Interference

Refer to the following table to rectify the fault.

| No. | Step |
|-----|---|
| 1 | Use shielded cables as the I/O signal cables and connect both ends of the shield to the PE terminal. |
| 2 | Connect the PE terminal of the motor to that of the drive, and connect the PE terminal of the drive to that of the power grid. |
| 3 | Add an equipotential bonding grounding cable between the host controller and the AC drive. |
| 4 | Install a magnetic ring to the U, V, and W output cables at the drive side and wind the cables through the magnetic ring for two to four turns. |
| 5 | Increase the filtering capacitance of the low-speed DI. The recommended maximum value is 0.1 μF . |
| 6 | Increase the filtering capacitance of the AI. The recommended maximum value is 0.22 μF . |
| 7 | Install a ferrite clamp or a magnetic ring to the signal cable and wind the signal cable through the magnetic ring for one to two turns. |
| 8 | Use a shielded power cable and properly ground its shield. |

10.4 RS485 and CAN Communication Interference

Obverse the following steps for troubleshooting.

| No. | Step |
|-----|--|
| 1 | Install a 120 Ω termination resistor at both ends of the bus. |
| 2 | Use multi-conductor shielded twisted pair cables and ground the shield at both ends. |
| 3 | Separate communication cables from power cables with a distance of at least 20 cm. |

| No. | Step |
|-----|---|
| 4 | Adopt the daisy chain mode for multi-node communication. |
| 5 | For multi-node communication, add an equipotential bonding grounding cable between nodes. |
| 6 | Add a ferrite clamp at both ends of the communication cable or add a magnetic ring at both ends of the communication cable and wind the communication cable through the magnetic ring for one to two turns. |
| 7 | Install a magnetic ring to the U, V, and W output cables at the drive side and wind the cables through the magnetic ring for two to four turns. |
| 8 | Use a shielded power cable and properly ground its shield. |

11 Certification and Standard Compliance

11.1 Compliance List

The following table lists the certifications, directives, and standards that the product may comply with. For details about the acquired certificates, see the certification marks on the product nameplate.

| Certification Name | Directive Name | | Standard Compliance |
|--------------------|----------------|------------|---------------------|
| CE Certification | EMC Directive | 2014/30/EU | EN IEC 61800-3 |
| | LVD | 2014/35/EU | EN 61800-5-1 |
| | RoHS Directive | 2011/65/EU | / |

11.2 CE Certification

11.2.1 Precautions for Compliance with European Standards



Figure 11-1 CE mark

- The CE mark indicates compliance with the Low Voltage Directive (LVD), Electromagnetic Compatibility (EMC), and Restriction of Hazardous Substances (RoHS) directives for commercial trades (production, import, and sales) in Europe.
- The CE mark is mandatory for engaging in commercial business (production, importation, and distribution) in Europe.
- The product complies with the LVD, EMC, and RoHS directives and is labeled with the CE mark.
- The machinery and devices equipped with this product must also meet CE requirements when sold in Europe.
- The integrator who integrates this drive into other products and attaches the CE mark to the final assembly has the responsibility of ensuring compliance with CE certification.

11.2.2 Requirements for Compliance with EMC Directive

- The drive is applicable to the first environment and second environment and complies with EMC directive 2014/30/EU and standard EN IEC 61800-3.



If the product is used in the first environment, it may generate radio interference. In addition to CE compliance requirements, measures should be taken to prevent interference when necessary.

-
- To enable the drive to comply with the EMC directive and standards, install an EMC filter on the input side and use shielded cables on the output side. Ground the filter properly. Ground the shield of the output cable in 360 degrees.



The manufacturer of the system with the product installed must ensure that the system meets the requirements of the European EMC Directive, and ensure that the system meets the requirements of the standard EN IEC 61800-3 according to the application environment of the system.

Introduction to EMC standards

Electromagnetic compatibility (EMC) describes the ability of electronic and electrical devices or systems to work properly in the electromagnetic environment and not to generate electromagnetic interference that influences other local devices or systems. EMC includes the following requirements:

- The electromagnetic interference generated by a device during normal operation must be restricted within a certain limit.
- The device must have sufficient immunity to electromagnetic interference in the environment and can work properly in the environment with electromagnetic interference, which is described as electromagnetic sensitivity.

EN IEC 61800-3 defines the following two environments:

- First environment: It includes domestic premises. It also includes establishments directly connected without intermediate transformer to a low-voltage power supply network which supplies buildings used for domestic purposes.
- Second environment: It includes all establishments other than those directly connected to a low-voltage power supply network which supplies buildings used for domestic purposes.

Devices are divided into the following four categories based on the intended application environment.

- C1 equipment: power drive system (PDS) with the rated voltage lower than 1000 V, which is intended for use in the first environment
- C2 equipment: PDS with the rated voltage lower than 1000 V, which is neither a plug-in device nor a movable device and is intended to be installed and commissioned only by professionals when used in the first environment.
- C3 equipment: PDS with the rated voltage lower than 1000 V, which is intended for use in the second environment and not intended for use in the first environment
- C4 equipment: PDS with the rated voltage equal to or higher than 1000 V or rated current equal to or higher than 400 A, or intended for use in complex systems in the second environment

11.2.3 Requirements for Compliance with the LVD

The drive has been tested in accordance with EN 61800-5-1 and has complied with the LVD. Observe the following requirements to enable machines and devices integrated with this drive to comply with the LVD.

Installation location

Install the drive in a place with overvoltage category III and pollution degree 1 or 2 as specified by IEC 60664-1.

Installation environment

For requirements of the installation environment, see ["2.1 Installation Environment" on page 22](#).

Installation protection requirements

- The drive serves as a part of a final system. Install the drive as the system component in a fireproof cabinet that provides effective electrical and mechanical protection, and install it in accordance with local laws and regulations and relevant IEC standards.
- For IP40-certified products, install them in structures where foreign objects cannot enter from the top or front sides.

Wiring of main circuit terminals

For details about the main circuit terminal wiring requirements, see ["3.4.2 Wiring Description of Main Circuit Terminals" on page 45](#).

Requirements for protective devices

To comply with EN 61800-5-1 standards, install a fuse/circuit breaker on the input side of the drive to prevent accidents caused by short circuit in the internal circuit. Use a fuse that matches the maximum input current of the AC drive. For selection of fuses, see ["9.5.4.1 Circuit Breaker, Fuse, and Electromagnetic Contactor" on page 93](#).

12 Service and Support

Documentation download

Product manuals, brochures, certificates, 2D/3D drawings and other information can be downloaded in the following way:

Go to our official website <https://www.inovance.com>, choose **Service and Support** > **Download**, enter keywords, and download the documentation.

Pre-sales consulting

We are honored to have you as our client. You can submit basic information to us in the following way, so that we can reach you as soon as possible. We are committed to your privacy. We will never share your information with any third party.

Go to our official website (<https://www.inovance.com>), choose **Service and Support** > **Contact Us**, and submit your information.

After-sales service

If you have product quality problems and need after-sales service, or you need to purchase spare parts, you can get the after-sales service person in your region through the following way.

Go to our official website (<https://www.inovance.com>), choose **Service and Support** > **After-sales Service**, and submit the product category and your region.

Repair service

If a product is faulty and needs to be repaired, you can check the maintenance instructions, submit the service request and check the service record in the following way.

Go to our official website (<https://www.inovance.com>), choose **Service and Support** > **Repair**, and submit the repair request.

Authentication

You can authenticate Inovance products in the following way:

Go to our official website (<https://www.inovance.com>), choose **Service and Support** > **Authentication**, and enter the 16-digit serial number.

FAQ

You can go through frequently asked questions about Inovance products in the following way:

Go to our official website (<https://www.inovance.com>) and choose **Service and Support** > **FAQ**.

Feedback

You can submit your feedback in the following way:

Go to our official website <https://www.inovance.com>, choose **Service and Support > Feedback**, and submit your feedback.

Forum

The forum provides high-quality courses for beginners and advanced learners. You are free to learn and share there. To get access to the forum:

Go to our official website <https://www.inovance.com> and choose **Service and Support > Forum**.



19012234B02

Copyright © Shenzhen Inovance Technology Co., Ltd.

Shenzhen Inovance Technology Co., Ltd.

www.inovance.com

Add.: Inovance Headquarters Tower, High-tech Industrial Park,
Guanlan Street, Longhua New District,
Shenzhen 518000, P.R. China

Tel: (0755) 2979 9595

Fax: (0755) 2961 9897

Suzhou Inovance Technology Co., Ltd.

www.inovance.com

Add.: No.52, Tian'e Dang Road, Wuzhong District,
Suzhou 215104, P.R. China

Tel: (0512) 6637 6666

Fax: (0512) 6285 6720