



MD600 Series

Compact AC Drive Quick Start Guide



19012337A00

1

1 Preface

The MD600 is a compact, general-purpose, and cost-effective AC drive for small automation equipment. Supporting Modbus RTU and CAN communication protocols, it features a compact size and high-performance open-loop vector control and can drive synchronous and asynchronous motors. The MD600 is widely used in small automation equipment in fields such as crystalline silicon, lithium battery, carpentry, logistics, cables, packaging, and machine tools.

This guide describes installation, wiring, keypad, commissioning, and parameters of the product. Read through this guide before use.

2 AC Drive Installation

Backplate mounting

T1 models (three-phase 380-480 V: 0.37-2.2 kW; single-phase 200-240 V: 0.37-1.5 kW) and T2 models (three-phase 380-480 V: 4-5.5 kW; single-phase 200-240 V: 2.2 kW) support backplate mounting.

Before installation, check that the installation tools and environment have been prepared. For details, see "Mechanical Design" in the MD600 Series Compact AC Drive Hardware Guide. This section describes quick backplate mounting steps.




Figure 2-1 Backplate mounting

3 AC Drive Wiring

3.1 Main Circuit Wiring

For details, see "Electrical Design" in the MD600 Series Compact AC Drive Hardware Guide. This section describes quick wiring steps. The following figure takes the CAN model as an example to introduce the main circuit wiring.

To wire the main circuit, do as follows:

1. Ground the AC drive.
2. Check the rated value of the circuit breaker or fuse.
3. Check whether the rated motor voltage is compatible with the AC drive voltage.
4. Connect the AC drive to the motor.
5. Connect the AC drive to the mains power.

3.2 Control Circuit Wiring

Precautions

I/O signals include analog input (AI), analog output (AO), digital input (DI), digital output (DO), and relay output signals. To avoid interference to the I/O signals, separate the I/O signal cables at least 20 cm away from the main circuit cables (R/S/T cables and U/V/W cables) and other power cables or power supply cables.

All wiring

All supports voltage input of -10 V to 10 V or 0 V to 10 V or current input of 0 mA to 20 mA.

Weak analog signals are easy to suffer external interference. Therefore, route the analog cable away from the interference source and keep the cable length as short as possible (no longer than 20 m). In applications where the analog signal suffers severe interference, install a filter capacitor or ferrite magnetic core at the analog signal source.




Figure 3-1 AI terminal wiring

Wiring of DI1 to DI5

When the OP terminal is connected to the internal 24 V power supply (DIP switch S4 set to 24V), do not short the COM and OP terminals. Otherwise, the internal 24 V power supply will be damaged.




Figure 3-2 Sink wiring

To use the internal 24 V power supply of the drive, which is the most commonly wiring method, set the DIP switch S4 to 24V (short the OP and 24V terminals), and connect the COM terminal of the drive to the 0V terminal of the external controller.

DO wiring

When the DO needs to drive a relay, connect a snubber diode on both sides of the relay coil. Otherwise, the 24 VDC power supply may be damaged. Ensure that the driving capacity does not exceed 50 mA.




Figure 3-3 Wiring between DO and relay



Connect the snubber diode with the polarity placed correctly. Otherwise, the DO circuit will be damaged upon the DO output.

DO: Optocoupler isolation; unipolarity open collector output

Output voltage range: 0 V to 24 V

Output current range: 0 mA to 50 mA

The DO is a unipolarity terminal and can be wired only in the following way.




Figure 3-4 Wiring between the DO and external controller

3.3 Terminal Description




Figure 3-5 Wiring for CAN models





Figure 3-6 Wiring for RS485 models

4 Keypad

4.1 Keypad Descriptions



4.2 Parameter Settings

You can set parameters through the AC drive keypad. Take F1-01 (Rated motor power) as an example to describe the operation through the keypad.

Press **F1** to enter the level 1 parameter menu. Press **▲**, **▼**, and **▶** to access **F1** group. Press **OK** to enter the level 2 parameter menu. Locate **F1-01** and press **OK** to enter the parameter setting interface. Press **▲**, **▼**, and **▶** to change the value of F1-01 to 3.7 kW, and then press **OK**. After the setting is saved, the interface automatically returns to the level 2 parameter menu and the monitoring interface.

5 Quick Operation

5.1 Basic Commissioning Flowchart




Figure 5-1 Basic commissioning flowchart



The following section introduces the required commissioning steps aiming at quick commissioning. For details, see MD600 Series Compact AC Drive Function Guide.

5.2 Wiring and Power-on Check

After connecting the drive properly, close the power supply switch and check the display on the keypad of the drive. If the keypad displays the set frequency (default: 50.00 Hz), the drive is powered on.

5.3 Factory Setting Restoration

Set A0-00 (Parameter initialization) to 3 to restore parameters (including motor parameters) to default settings.

Para. Code	Para. Name	Default	Value	Description
A0-00	Parameter initialization	0	0: No operation 1: Restore parameters (excluding motor parameters) to default settings 2: Restore parameters (including motor parameters) to default settings	0: No operation 1: AC drive parameters except factory parameters, motor parameters, and records are restored to default settings. 2: V/f control (speed open loop control) 3: AC drive parameters except factory parameters and records are restored to default settings.

5.4 Motor Parameter Settings

Set motor parameters according to the motor nameplate, including the motor type, rated motor power, voltage, current, frequency, and speed, motor power factor, maximum frequency, and minimum frequency.



If the motor is a synchronous motor with a large load that cannot be disconnected, perform static auto-tuning and manually set the line voltage of the back EMF after auto-tuning.

Para. Code	Para. Name	Default	Value	Description
F1-00	Motor type	0	0: Common asynchronous motor 2: Permanent magnet synchronous motor	It is used to set the motor type.
F1-01	Rated motor power	3.7	0.1 kW to 1000.0 kW	It is used to set the rated motor power in the unit of kW.
F1-03	Rated motor voltage	380	1 V to 2000 V	It is used to set the rated motor voltage in the unit of V.
F1-04	Rated motor current	9.00	0.01 A to 655.35 A	It is used to set the rated motor current in the unit of A.
F1-06	Rated motor frequency	50.00	0.01 Hz to 599.00 Hz	It is used to set the rated motor frequency in the unit of Hz.
F1-07	Rated motor speed	1460	1 rpm to 65535 rpm	It is used to set the rated motor speed in the unit of rpm.
F1-10	Maximum motor frequency	50.00	F1-06 to 599.00 Hz	It is used to set the allowed maximum frequency of the motor in the unit of Hz.
F1-11	Minimum motor frequency	0.00	0.00 Hz to F1-10	It is used to set the allowed minimum frequency of the motor in the unit of Hz.
F1-12	Synchronous motor back EMF	300 V	0 V to 6553.5 V	It is used to set the effective value of the linear back EMF of the synchronous motor at rated speed. The value is obtained through auto-tuning.

5.5 Motor Control Mode Settings

You can set the motor control mode through F0-01 (Motor control mode). The drive supports the V/f control mode and SVC mode. As an open loop vector control mode, the SVC is applicable for high-performance control scenarios in which one AC drive can drive only one motor, such as the machine tool, centrifuge, drawing machine, and injection molding machine. If this mode is selected, parameter auto-tuning is required to obtain accurate parameters and maximize the advantage of the SVC mode. V/f is an open loop control mode based on constant voltage and frequency ratio. This mode is applicable to scenarios without high requirements on load control performance, such as fans and water pumps and scenarios without high requirements on accuracy of parameters. This mode is simply and easy to use. The dynamic performance of the V/f control mode is not as good as that of the SVC mode.



When F1-00 (Motor type) is set to 0 (Common asynchronous motor), F0-01 (Motor control mode) can be set according to the application requirements. When F1-00 (Motor type) is set to 2 (Permanent magnet synchronous motor), the SVC mode is recommended. The accuracy is low for the synchronous motor in the V/f control.

Para. Code	Para. Name	Default	Value	Description
F0-01	Motor control method	0	0: SVC (sensorless vector control) 2: V/f control (speed open loop control)	It is used to set the motor control mode based on the application scenario and motor type.

5.6 Motor Auto-tuning

The auto-tuning mode can be set by F1-69 (Auto-tuning mode). Select the auto-tuning mode based on the motor type and load condition. Press **OK** after selecting the auto-tuning mode. The AC drive displays "TUNE". Press **▲**, **▼**, and the motor auto-tuning starts. When the current set frequency (50.00 Hz by default) is displayed, auto-tuning is completed. The auto-tuning process usually lasts for three minutes. Do not operate the AC drive during this period. Wait for the auto-tuning process to complete. After auto-tuning, parameters C4-20 to C4-64 are obtained and written.



Before performing static partial parameter auto-tuning of the synchronous motor, enter F1-12 (Synchronous motor back EMF) manually.

